

FIRST DRAFT

WA80M-7

WA100M-7

WHEEL LOADER

Model:

WA80M-7
WA100M-7

Serial number:

H62051 AND UP
H62051 AND UP

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local KOMATSU distributor for those items you may require.
- Materials and specifications are subject to change without notice.
- The Wheel Loader WA80M-7 is equipped with the engine SAA4D95LE-6.
The Wheel Loader WA100M-7 is equipped with the engine SAA4D95LE-6.
- For details of this engine see Engine Manual: WA80M-7, WA100M-7 in attachment

Contents

Contents	0-1
----------------	-----

Safety

Safety notice	0-2
Preparations for work	0-3
Tipping up the driver's cab	0-4
Tipping down the driver's cab	0-6
Precautions during work	0-8
Hydraulic system	0-9
Foreword	0-10
General	0-10
Structure and function	0-10
Testing and adjusting	0-10
Disassembly and assembly	0-10
Maintenance standard	0-10
How to read the shop manual	0-11
Volumes	0-11
Distribution and updating	0-11
Filing method	0-11
Symbols	0-12
Hoisting instructions	0-13
Wire ropes	0-13

General

Dimensions, weights and operating data	1-2
Specifications	1-4
WA80M-7 – Specifications	1-4
WA100M-7 – Specifications	1-5
Weight tables	1-6
WA80M-7 – Weight table	1-6
WA100M-7 – Weight table	1-6
Lubricants and operating mediums	1-7
WA80M-7 – Lubricants and operating mediums	1-7
WA100M-7 – Lubricants and operating mediums	1-8
Basic procedures of maintenance	1-9
Oil	1-9
Fuel	1-9
Coolant	1-10
Grease	1-10
Storing oil and fuel	1-10
Filters	1-11
Biodegradable hydraulic oils and lubricants	1-11
Outline of electric system	1-11
Torque list – Screws and nuts	1-12

Structure and Function

Powertrain	10-5
Closed circuit	10-6
Hydraulic drive system	10-7
WA80M-7 – Hydraulic drive system – 20 km/h and 30 km/h	10-7
WA100M-7 – Hydraulic drive system – 20 km/h and 30 km/h	10-8
Variable displacement pump (HST pump)	10-9
Regulating valve (DA valve)	10-12
WA80M-7 - Charge pump pressure relief valve - 20km/h	10-13
WA80M-7 , WA100M-7 - Charge pump pressure relief valve - 30km/h.	10-13
Control cylinder	10-14
4/3 Way valve with direction control solenoids	10-15
Pressure cut-off valve	10-16
Safety & charge valve	10-17
Towing	10-18
Variable displacement motor (HST motor with HA Control)	10-19
Hydraulic diagram HST motor A6VM85 (or 150) HA1R1	10-21
Directional shuttle valve	10-22
Auto inch valve diagram (option)	10-22
HST motor with DA Control	10-23
Hydraulic diagram HST Motor A6VM107(160)DA2	10-24
Drive shaft	10-25
Front axle – Mounting	10-26
WA80M-7, WA100M-7 – Front axle mounting	10-26
Rear axle – Mounting	10-27
Front axle	10-28
WA80M-7 – Front axle with inner disc brake as service brake and outer disc brake as parking brake. .	10-28
WA100M-7 – Front axle with inner disc brake as service brake and outer disc brake as parking brake.	10-29
Rear axle with transfer box	10-30
WA80M-7 – Rear axle with transfer box	10-30
WA100M-7 – Rear axle with transfer box	10-31
Transfer box TB172	10-32
Limited slip differential	10-34
Limited slip differential – Locking value 25%	10-34
Locking differential	10-36
Locking differential – Locking value 100%	10-36
Wheel hub – Font axle and rear axle	10-38
Service and parking brake – Front axle	10-40
WA80M-7, WA100M-7 – Service brake	10-40
WA80M-7, WA100M-7 – Parking brake	10-41

Service and parking brake circuit	10-42
WA80M-7 – Service and parking brake circuit	10-42
WA100M-7 – Service and parking brake circuit	10-43
Service brake assembly	10-44
WA80M-7, WA100M-7 – Service brake assembly	10-44
Main-brake valve	10-45
WA80M-7, WA100M-7 – Main-brake valve	10-45
Steering articulation joint	10-46
Steering system	10-48
WA80M-7 – Hydraulic circuit diagram of steering system	10-48
WA100M-7 – Hydraulic circuit diagram of steering system	10-50
Priority valve	10-52
Orbit-roll-valve	10-53
Steering relief valve	10-54
Work equipment hydraulic	10-56
WA80M-7 – Travel, steering and work hydraulics	10-56
WA100M-7 – Travel, steering and work hydraulics	10-58
PPC-Valve WA100M-7	10-60
Operation of PPC-valve	10-61
Servo pressure regulating valve	10-62
Emergency Lowering System	10-62
Main control valve	10-63
Main control valve WA80M-7	10-63
Main control valve WA100M-7	10-64
Lift cylinder	10-65
WA80M-7 – Lift cylinder	10-65
WA100M-7 – Lift cylinder	10-66
Dump cylinder	10-67
WA80M-7 – Dump cylinder	10-67
WA100M-7 – Dump cylinder	10-68
Steering cylinder	10-69
WA80M-7 – Steering cylinder	10-69
WA100M-7 – Steering cylinder	10-70
Loader Linkage with quick-coupler	10-71
WA80M-7, WA100M-7 – Loader Linkage with quick-coupler	10-71
Quick-coupler	10-72
WA80M-7 – Quick-coupler	10-72
WA100M-7 – Quick-coupler	10-73
Monitor display	10-74
WA80M-7, WA100M-7 – Monitor display	10-74
Special monitor functions	10-76
Monitor Service Menu	10-78

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$