SEBMU1440102

Shop Manual

D68E-1 D68P-1

BULLDOZER

 SERIAL NUMBERS
 D68E-1
 1001 and up

 D68E-1A (BRAZILIAN)
 B1001 and up
 D68P-1
 45590 and up

 D68P-1A (BRAZILIAN)
 B1001 and up
 D68P-1A (BRAZILIAN)
 B1001 and up



www.KomatsuAmerica.com

CONTENTS

	No	of page
10	ENGINE	
	11 STRUCTURE AND FUNCTION	11-1
	12 TESTING AND ADJUSTING	12-1
	13 DISASSEMBLY AND ASSEMBLY	13-1
20	POWER TRAIN	
	21 STRUCTURE AND FUNCTION	21-1
	22 TESTING AND ADJUSTING	22-1
	23 DISASSEMBLY AND ASSEMBLY	23-1
	24 MAINTENANCE STANDARD	24-1
30	UNDERCARRIAGE	
	31 STRUCTURE AND FUNCTION	31-1
	33 DISASSEMBLY AND ASSEMBLY	33-1
	34 MAINTENANCE STANDARD	34-1
60	HYDRAULIC SYSTEM	
	61 STRUCTURE AND FUNCTION	61-1
	62 TESTING AND ADJUSTING	62-1
	63 DISASSEMBLY AND ASSEMBLY	63-1
	64 MAINTENANCE STANDARD	64-1
70	WORK EQUIPMENT	
	71 STRUCTURE AND FUNCTION	71-1
	73 DISASSEMBLY AND ASSEMBLY	. 73-1
	74 MAINTENANCE STANDARD	74-1
80	ELECTRIC AND ELECTRONIC SYSTEM	
	81 STRUCTURE AND FUNCTION	81-1

The affected pages are indicated by the use of the following marks. It is requested that necessary actions must be taken to these pages according to the list below.

Mark	Indication	Action required			
0	Page to be newly added	Add			
•	Page to be replaced	Replace			
()	Page to be deleted	Discard			

Pages having no marks are not revised at this time.

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
•	00- 1	1	0	13-12	1		21-22			22- 3		0	23-24	1
•	00-2	1	0	13-13	1		21-23			22-4		0	23-25	$\tilde{\mathbb{O}}$
0	00- 2-	·1 ①	0	13-14	1		21-24			22- 5		0	23-26	Ũ
0	00- 2-	·2 ①	0	13-15	1		21-25			22- 6		0	23-27	1
	00- 3		0	13-16	1		21-26			22-7		0	23-28	1
	00- 4		0	13-17	1		21-27			22-8		0	23-29	\bigcirc
	00- 5		0	13-18	1		21-28			22-9		0	23-30	1
	00- 6		0	13-19	1		21-29			22-11		0	23-31	\bigcirc
	00- 7		0	13-20			21-30			22-12		0	23-32	1
	00-8		0	13-21	1		21-31			22-13		0	23-33	\bigcirc
	00-9		0	13-22	\bigcirc		21-32			22-14		0	23-34	\bigcirc
	00-10		0	13-23	1		21-33			22-15		0	23-35	\bigcirc
	00-11		0	13-24	1		21-35			22-16		0	23-36	\bigcirc
	00-12		0	13-25	1		21-36			22-17		0	23-37	\bigcirc
	11- 1		0	13-26	1		21-37			22-18		0	23-38	\bigcirc
	11-2		0	13-27	1		21-38			22-19		0	23-39	1
	11-3		0	13-28	1		21-39			22-20	~	0	23-40	1
	11-4		0	13-29	1		21-40		0	23- 1	(1)	0	23-42	1
	11-5		0	13-30	1		21-42		0	23-2	1	0	23-43	1
	11-6		0	13-31	\bigcirc		21-43		0	23- 3	1	0	23-44	1
	11-8			21-1			21-44		0	23- 4	1	0	23-45	1
	11-9			21-2			21-45		0	23- 5	1	0	23-46	1
	12-1			21-3			21-46		0	23- 6	1	0	23-47	\bigcirc
	12-2			21-4			21-48		0	23-7	0	0	23-48	\bigcirc
	12-3			21- 5 21- 6			21-49		Ο.	23-8	1	0	23-49	1
	12-4 12-5			21- 0			21-50		0	23-9	1	0	23-50	\bigcirc
	12- 5			21- 7			21-51		0	23-10	0	0	23-51	1
	12- 0			21-10			21-52		0	23-11	1	0	23-52	1
0	12- 7	1		21-10			21-53		0	23-12	0	0	23-53	1
0	13- 1	1		21-12			21-54		0	23-13	0	0	23-54	1
0	13- 2	1		21-12			21-55		0	23-14	1	0	23-55	1
0	13- 3	1		21-13			21-56		0	23-15	0	0	23-56	1
0	13-4	1		21-14			21-57		0	23-16	<u> </u>	0	23-57	1
0	13- 5	1		21-15			21-58 21-59		0	23-17	_	0	23-58	1
0	13- 0	1		21-10			21-59		0	23-18	-	0	23-59	1
0	13- 7	1		21-17			21-60		0	23-19 23-20	0	0	23-60	1
0	13- 0	1		21-18			21-61		0	23-20	-	0	23-61	
0	13-9	1		21-20			21-02		0	23-21	1 1	0	23-62	1
0	13-11	1		21-21			22- 2		0	23-22		0	23-63	1
		\cup		2, 21			~~ ~			20 20	U	0	23-64	1

LIST OF REVISED PAGES

It's a preview. You can download the full file by clicking the link below.

https://shopservicemanual.com/

Service Manuals from 2\$