

Shop Manual

HYDRAULIC
EXCAVATOR

PC20MR-3

SERIAL NUMBERS 20001 and up

KOMATSU

HYDRAULIC EXCAVATOR

PC20MR-3

Machine model	Serial number
PC20MR-3	20001 and up

00 Index and foreword

100 Index

Composition of shop manual	2
Table of contents	3

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly.

The marks shown to the right of Form No. denote the following:

○: New issue (to be filed additionally) ●: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:

- Place a divider on the top of each section in the file after matching the Tub No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

Section Title	Form Number
Shop Manual, contents binder, binder label and tabs	SEN04767-03
00 Index and foreword	SEN04768-03
100 Index	SEN04769-03 ●
200 Foreword and general information	SEN04770-00
01 Specification	SEN04771-00
100 Specification and technical data.....	SEN04772-00
10 Structure, function and maintenance standard.....	SEN04773-00
100 Engine and cooling system	SEN04774-00
200 Power train.....	SEN04775-00
300 Undercarriage and frame	SEN04776-00
410 Hydraulic system, Part 1	SEN04777-00
420 Hydraulic system, Part 2	SEN04778-00
430 Hydraulic system, Part 3	SEN04779-00
500 Work equipment.....	SEN04780-00
600 Cab and its attachments	SEN04781-00
700 Electrical system	SEN04782-00
20 Standard value table.....	SEN04783-01
100 Standard service value table.....	SEN04867-01
30 Testing and adjusting	SEN04784-00
100 Testing and adjusting	SEN04868-00
40 Troubleshooting.....	SEN04785-01
100 General information on troubleshooting.....	SEN04869-00
200 Troubleshooting of electrical system (E-mode).....	SEN04870-00
300 Troubleshooting of hydraulic and mechanical system (H-mode)	SEN04871-00
400 Troubleshooting of engine (S-mode).....	SEN04872-00
500 Troubleshooting of Machine monitor System(M-mode)	SEN04873-01 ●
50 Disassembly and assembly.....	SEN04786-00
100 General information on disassembly and assembly	SEN04874-00
200 Engine and cooling system	SEN04875-00

300 Power train	SEN04876-00
400 Undercarriage and frame	SEN04877-00
500 Hydraulic system	SEN04878-00
600 Work equipment	SEN04879-00
700 Cab and its attachments.....	SEN04880-00
800 Electrical system	SEN04881-00
90 Diagrams and drawings.....	SEN04787-01
100 Hydraulic diagrams and drawings	SEN04788-00
200 Electrical diagrams and drawings.....	SEN04789-01

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$