

SHOP MANUAL

GALEO

PC27MR-2 PC30MR-2

PC35MR-2 PC40MR-2

PC50MR-2

HYDRAULIC EXCAVATOR

SERIAL NUMBER

PC27MR-2 15001 and up

PC30MR-2 20001 and up

PC35MR-2 5001 and up

PC40MR-2 8001 and up

PC50MR-2 5001 and up

KOMATSU
Utility

SHOP MANUAL

KOMATSU

PC27MR-2 PC30MR-2 PC35MR-2 PC40MR-2 PC50MR-2

MACHINE MODEL

SERIAL NUMBER

PC27MR-2

15001 and up

PC30MR-2

20001 and up

PC35MR-2

5001 and up

PC40MR-2

8001 and up

PC50MR-2

5001 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PC27MR-2 mount the 3D82AE-5M, PC30MR-2 mount the 3D84E-5N, PC35MR-2 mount the 3D88E-5P and PC40, 50MR-2 mounts the 4D88E-5X engine.
- For details of the engine, see the 68E-88E Series Engine Shop Manual.

CONTENTS

	No. of page
01 GENERAL	01-1
10 STRUCTURE, FUNCTION AND MAINTENANCE STANDARD.....	10-1
20 TESTING AND ADJUSTING	20-1
30 DISASSEMBLY AND ASSEMBLY	30-1
90 OTHERS	90-1

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
()	Page to be deleted	Discard

Pages having no marks are those previously revised or made additions.

LIST OF REVISED PAGES

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
●	00-1	(5)		01-13	(1)		10-31			10-68	(1)		10-93	(3)
	00-2	(2)		01-14	(1)		10-32			10-69			10-94	(3)
●	00-2-1	(5)		01-15	(1)		10-33	(3)		10-70	(3)		10-94-1	(3)
●	00-2-2	(5)		01-16	(3)		10-33-2	(3)		10-70-1	(3)		10-94-2	(3)
●	00-2-3	(5)		01-17	(3)		10-34			10-70-2	(3)		10-95	(1)
	00-3			01-18	(3)		10-35			10-70-3	(3)		10-96	(1)
	00-4			01-19	(3)		10-36			10-70-4	(3)		10-97	(1)
	00-5			01-20	(3)		10-37	(3)		10-70-5	(3)		10-98	(1)
	00-6			01-21			10-38			10-70-6	(3)		10-99	(1)
	00-7						10-39			10-70-7	(3)		10-100	(3)
	00-8			10-1			10-40			10-70-8	(3)		10-101	
	00-9			10-2	(3)		10-41			10-70-9	(3)		10-102	
	00-10			10-3	(3)		10-42			10-70-10	(3)		10-103	(3)
	00-11			10-3-2	(3)		10-43			10-70-11	(3)		10-104	
	00-12			10-4	(3)		10-44			10-70-12	(3)		10-105	
	00-13			10-5	(3)		10-44-1	(3)		10-71	(1)		10-106	
	00-14			10-6			10-45	(3)		10-72			10-108	(3)
	00-15			10-7	(3)		10-46	(3)		10-73			10-109	
	00-16			10-8	(3)		10-47	(3)		10-74			10-110	(3)
	00-17			10-9			10-48	(3)		10-75	(3)		10-110-2	(3)
	00-18			10-10			10-49	(3)		10-76	(1)		10-111	(3)
	00-19			10-11			10-50			10-77	(3)		10-112	
	00-20			10-12	(3)		10-51			10-78			10-113	(3)
	00-21			10-12-2	(3)		10-52			10-79	(3)		10-114	
	00-22			10-13	(3)		10-53			10-79-1	(1)		10-115	
				10-14	(3)		10-54	(3)		10-79-2	(1)		10-116	
	01-1			10-15	(3)		10-55			10-80			10-117	
	01-2	(3)		10-16	(3)		10-56	(3)		10-81	(1)		10-118	(3)
	01-3	(3)		10-17	(3)		10-57	(3)		10-82			10-119	
	01-4	(3)		10-18	(3)		10-58			10-83			10-120	
	01-4-1	(3)		10-19	(3)		10-59			10-84			10-121	
	01-4-2	(3)		10-20	(3)		10-60	(1)		10-85			10-122	(3)
	01-4-4	(3)		10-22	(3)		10-61	(1)		10-86			10-123	
	01-5	(1)		10-23			10-61-1	(1)		10-87	(3)		10-124	
	01-6	(1)		10-24	(3)		10-61-2	(1)		10-88			10-126	(3)
	01-7	(1)		10-25			10-62			10-89			10-127	
	01-8	(1)		10-26			10-63			10-90			10-128	(3)
	01-9	(1)		10-27			10-64	(3)		10-90-2	(1)		10-129	
	01-10	(1)		10-28	(3)		10-65			10-90-3	(3)		10-130	(3)
	01-11	(1)		10-29			10-66	(3)		10-91			10-131	
	01-12	(1)		10-30	(3)		10-67			10-92			10-132	

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$