

SHOP MANUAL

KOMATSU

PC60-5 PC60L-5 PC60U-5

MACHINE MODEL	SERIAL No.
PC60-5	20501 and up
PC60L-5	7501 and up
PC60U-5	4501 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PC60, 60L and 60U mount the 4D95L-1 engine.
For details of the engine, see the 95 series engine Shop Manual.

CONTENTS

10 ENGINE	No. of page
11 STRUCTURE AND FUNCTION	11-1
12 TESTING AND ADJUSTING	12-1
13 DISASSEMBLY AND ASSEMBLY	13-1
20 POWER TRAIN	
21 STRUCTURE AND FUNCTION	21-1
23 DISASSEMBLY AND ASSEMBLY	23-1
24 MAINTENANCE STANDARD	24-1
30 UNDERCARRIAGE	
31 STRUCTURE AND FUNCTION	31-1
33 DISASSEMBLY AND ASSEMBLY	33-1
34 MAINTENANCE STANDARD	34-1
60 HYDRAULIC SYSTEM	
61 STRUCTURE AND FUNCTION	61-1
62 TESTING AND ADJUSTING	62-1
63 DISASSEMBLY AND ASSEMBLY	63-1
64 MAINTENANCE STANDARD	64-1
70 WORK EQUIPMENT	
73 DISASSEMBLY AND ASSEMBLY	73-1
80 ELECTRICAL SYSTEM	
81 STRUCTURE AND FUNCTION	81-1
82 TESTING AND ADJUSTING	82-1

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
()	Page to be deleted	Discard

Pages having no marks are those previously revised or made additions.

LIST OF REVISED PAGES

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
●	00-1	⑤		13-1	③		21-16	②	●	23-18	⑤		31-6	
	00-2	③		13-2	①		21-17	②	●	23-19	⑤		31-7	
●	00-2-1	⑤		13-2-1	③		21-18		●	23-20	⑤			
	00-2-2	④		13-3	①		21-19		●	23-21	⑤		33-1	④
	00-3			13-4	①		21-20	②	●	23-22	⑤		33-2	①
	00-4			13-5	①		21-21		●	23-23	⑤		33-3	①
	00-5			13-6	①		21-22		●	23-24	⑤		33-4	④
	00-6			13-7	①		21-23	③	○	23-24-1	⑤		33-5	④
	00-7			13-8	①		21-24		○	23-24-2	⑤		33-6	④
	00-8			13-9	①		21-25			23-25	①		33-7	④
	00-9			13-10	①		21-26			23-26	①		33-8	④
	00-10			13-11	①		21-27			23-27	①		33-9	④
				13-12	①		21-28	③		23-28	①		33-10	④
	11-1			13-13	①		21-29	③		23-29	①			
	11-2			13-14	①		21-30	③		23-30	①		34-1	
	11-3			13-15	①		21-31	③		23-31	①		34-2	
	11-4			13-16	①		21-32	②		23-32	①		34-3	
	11-5			13-17	①		21-33	②		23-33	①		34-4	
	11-6			13-18	①		21-34			23-34	①		34-5	
	11-7	③		13-19	①		21-35			23-35	①		34-6	
	11-8	③		13-20	①		21-36			23-36	①		34-7	
	11-9	③		13-21	①					23-37	①			
	11-10			13-22	①		23-1	①		23-38	①		61-1	③
	11-11						23-2	①		23-39	①		61-2	
	11-12			21-1			23-3	①		23-40	①		61-3	
	11-13			21-2	②		23-4	①		23-41	①		61-4	
	11-14			21-3			23-5	①		23-42	①		61-6	
				21-4	②		23-6	①		23-43	①		61-7	②
	12-1	③		21-5		●	23-7	⑤		23-44	①		61-7-1	②
	12-2	①		21-6		●	23-8	⑤					61-7-2	②
	12-3	①		21-7		●	23-9	⑤		24-1			61-8	②
	12-4	①		21-8		●	23-10	⑤		24-2			61-8-2	②
	12-5	①		21-9		●	23-11	⑤		24-3			61-9	②
	12-6	①		21-10		●	23-12	⑤		24-4	②		61-9-1	②
	12-7	①		21-11		●	23-13	⑤		24-5			61-9-2	②
	12-8	①		21-12		●	23-14	⑤					61-10	②
	12-9	①		21-13		●	23-15	⑤		31-1			61-12	
	12-10	③		21-14		●	23-16	⑤		31-2			61-13	②
	12-11	③		21-15		●	23-17	⑤		31-3			61-14	
										31-4			61-15	
										31-5			61-16	
													61-17	

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
	61-18		61-74		②	62-41		③	62-94		③	63-42		①
	61-20		61-75		②	62-42		③	62-95		③	63-43		①
	61-21		61-76			62-43		③	62-96		③	63-44		①
	61-22					62-44		③	62-97		③			
	61-23	③	62-1		③	62-45		③	62-98		③	64-1		
	61-24	③	62-2		③	62-46		③	62-99		③	64-3		
	61-25		62-3		①	62-47		③				64-4		
	61-26		62-4		③	62-48		③	63-1		③	64-5		
	61-27	③	62-5		①	62-49		③	63-2		①	64-6		
	61-28	③	62-6		①	62-51		③	63-3		①	64-7		
	61-29	③	62-7		①	62-52		③	63-4		①	64-8		
	61-30	③	62-8		①	62-53		③	63-5		①	64-9		
	61-31	③	62-8-1		③	62-54		③	63-5-1		③	64-10		
	61-33	③	62-8-2		③	62-55		③	63-5-2		③	64-11		
	61-34	③	62-8-3		③	62-56		③	63-6		①	64-12		
	61-35	③	62-8-4		③	62-57		③	63-7		①	64-13		
	61-37	③	62-8-5		③	62-58		③	63-8		①	64-14		
	61-38	③	62-8-6		③	62-59		③	63-9		①	64-15		
	61-39	③	62-8-7		③	62-60		③	63-10		①			
	61-40	③	62-8-8		③	62-61		③	63-11		①	73-1		①
	61-41	③	62-9		③	62-62		③	63-12		①	73-2		①
	61-42	③	62-10		①	62-63		③	63-13		①	73-3		①
	61-43	③	62-11		①	62-64		③	63-14		①	73-4		①
	61-44	③	62-12		①	62-65		③	63-15		①	73-5		①
	61-45	③	62-13		①	62-66		③	63-16		①	73-6		①
	61-46	③	62-14		③	62-67		③	63-17		①			
	61-47	③	62-15		①	62-68		③	63-18		①	81-1		
	61-48	③	62-15-1		③	62-69		③	63-19		①	81-2		②
	61-49	③	62-15-2		③	62-70		③	63-20		①	81-3		②
	61-50	③	62-15-3		③	62-71		③	63-20-1		③	81-4		②
	61-51	③	62-16		③	62-72		③	63-20-2		③	81-5		③
	61-52	②	62-17		①	62-73		③	63-20-3		③			
	61-53		62-18		①	62-74		③	63-21		③	82-1		③
	61-54	②	62-19		①	62-75		③	63-22		①	82-2		③
	61-55		62-20		①	62-76		③	63-23		①	82-3		③
	61-56	②	62-21		③	62-77		③	63-24		①	82-4		③
	61-57		62-22		①	62-78		③	63-25		①	82-5		③
	61-58		62-23		①	62-79		③	63-26		①	82-6		③
	61-59		62-24		①	62-80		③	63-27		①			
	61-60		62-25		①	62-81		③	63-28		①			
	61-61		62-26		③	62-82		③	63-29		①			
	61-62		62-28		①	62-83		③	63-30		①			
	61-64		62-29		①	62-84		③	63-31		①			
	61-65		62-30		①	62-85		③	63-32		①			
	61-66		62-31		①	62-86		③	63-33		①			
	61-67		62-33		③	62-87		③	63-34		①			
	61-68	②	62-34		③	62-88		③	63-35		①			
	61-69	②	62-35		③	62-89		③	63-36		①			
	61-70	②	62-36		③	62-90		③	63-37		①			
	61-71	②	62-37		③	62-91		③	63-38		①			
	61-72	②	62-39		③	62-92		③	63-39		①			
	61-73	②				62-93		③	63-40		①			
									63-41		①			

ENGINE

11 STRUCTURE AND FUNCTION



Engine mount	11-2
Radiator	11-3
PTO	11-4
Fuel tank and piping	11-5
Engine control	11-6
Auto-deceleration system (If equipped)	11-7

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$