

Shop Manual

HYDRAULIC
EXCAVATOR

PC88MR-8

SERIAL NUMBERS F80003 and up

ecot3

KOMATSU

HYDRAULIC EXCAVATOR

PC88MR-8

Machine model **Serial number**
PC88MR-8 F80003 and up

00 Index and foreword

100 Index

Composition of shop manual	2
Table of contents	4

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly.

The marks shown to the right of Form No. denote the following:

○: New issue (to be filed additionally) ●: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:

- Place a divider on the top of each section in the file after matching the Tab No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

Section Title.....	Form Number
Shop Manual, contents binder, binder label and tabs	WENBM00020
00 Index and foreword	
100 Index	WEN04338-12
200 Foreword and general information	WEN04339-02
01 Specification	
100 Specification and technical data.....	WEN04340-01
10 Structure, function and maintenance standard	
100 Engine and cooling system	WEN04464-01
200 Power train.....	WEN04465-01
300 Undercarriage and frame	WEN04466-01
410 Hydraulic system, Part 1	WEN04467-03
420 Hydraulic system, Part 2.....	WEN04468-01
430 Hydraulic system, Part 3.....	WEN04469-04
500 Work equipment.....	WEN04470-00
600 Cab and its attachments	WEN04471-02
700 Electrical system.....	WEN04472-05
20 Standard value table	
100 Standard service value table.....	WEN04443-03
30 Testing and adjusting	
110 Testing and adjusting, Part 1.....	WEN04444-06
120 Testing and adjusting, Part 2.....	WEN04445-04
130 Testing and adjusting, Part 3.....	WEN04446-01
40 Troubleshooting	
100 Failure code table and fuse locations	WEN04447-03
200 General information on troubleshooting.....	WEN04448-02
310 Troubleshooting by failure code, Part 1	WEN04449-03
320 Troubleshooting by failure code, Part 2	WEN04450-04
330 Troubleshooting by failure code, Part 3	WEN04451-01
340 Troubleshooting by failure code, Part 4	WEN04452-01
400 Troubleshooting of electrical system (E-mode).....	WEN04453-01

500	Troubleshooting of hydraulic and mechanical system (H-mode).....	WEN04454-01
600	Troubleshooting of engine (S-mode).....	WEN04455-01
50 Disassembly and assembly		
100	General information on disassembly and assembly.....	WEN04456-02
200	Engine and cooling system	WEN04457-04
300	Power train	WEN04458-01
400	Undercarriage and frame	WEN04459-02
500	Hydraulic system.....	WEN04460-01
600	Work equipment	WEN04461-00
700	Cab and its attachments.....	WEN04462-00
800	Electrical system	WEN04463-03
90 Diagrams and drawings		
100	Hydraulic diagrams and drawings	WEN04341-01
200	Electrical diagrams and drawings	WEN04342-01

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$