

Shop Manual

94 Series

DIESEL ENGINE

This material is proprietary to Komatsu America Corp. and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu America Corp.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

Copyright 2010 Komatsu
Printed in U.S.A.
Komatsu America Corp.

July 1992

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
()	Page to be deleted	Discard

Pages having no marks are not revised.

LIST OF REVISED PAGES

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
●	00- 1	③		01-025			11-202			11-501			12-306	
●	00- 2	③		01-026			11-203			11-502	②		12-307	
●	00- 2-1	③		01-027			11-204			11-503	②		12-308	
●	00- 3	③		01-027-1	②		11-204-1	②		11-504	②		12-309	
	00- 4	②		01-027-2	②		11-205	②		11-505	②		12-310	
	00- 5			01-027-3	②		11-206	②		11-506	②		12-311	
	00- 6			01-027-4	②		11-207	②		11-801			12-312	
	00- 7		●	01-028	③		11-207-1	②		11-802			12-313	
●	00- 8	③		01-029	②		11-207-3	②		11-803	②		12-314	
	00- 9		●	01-030	③		11-207-4	②		11-803-1	②		12-315	
	00-10			01-031			11-208			11-804	②		12-316	
	00-11			01-032	②		11-209	②		11-804-1	②		12-401	②
	01-001	②		01-033			11-210	②	●	11-804-2	③		12-402	
	01-002		●	01-034	③		11-211	②	●	11-805	③		12-403	
	01-003		●	01-035	③		11-212			11-806	②		12-404	
	01-004		●	01-036	③		11-213			11-807	②		12-405	
	01-005		●	01-037	③		11-214			12-001	②		12-406	
	01-005-1	②	●	01-038	③		11-215	②		12-002			12-407	
	01-006	②	●	01-039	③		11-216	②		12-003			12-408	②
●	01-007	③	●	01-040	③		11-217	②		12-004	②		12-409	②
●	01-008	③	●	01-041	③		11-301			12-005			12-410	②
●	01-009	③	●	01-042	③		11-302			12-006			12-411	②
	01-010	②	●	01-043	③	●	11-303	③		12-101			12-412	②
●	01-011	③	●	01-044	③		11-304	②		12-102			12-413	②
●	01-011-1	③	●	01-045	③		11-304-1	②		12-103			12-414	②
●	01-011-2	②	●	01-046	③		11-305			12-104			12-415	②
●	01-011-3	③	●	01-047	③	●	11-306	③		12-105	②		21-416	②
	01-012		○	01-048	③		11-401			12-106	②		12-417	②
	01-013			11-001	②		11-402			12-107			12-417-1	②
	01-014			11-002			11-403			12-201			12-417-2	②
	01-015			11-003			11-404		●	12-202	③		12-417-3	②
	01-016			11-004	②		11-405			12-203			12-417-4	②
	01-017			11-005			11-406			12-204			12-417-5	②
	01-018			11-006	②		11-407			12-205			12-417-6	②
	01-019			11-007			11-408			12-206			12-417-7	②
	01-020			11-008	②		11-409			12-301			12-417-8	②
	01-021			11-009	②		11-410	②		12-302			12-417-9	②
	01-022			11-010	②		11-410-1	②		12-303			12-417-10	②
	01-023			11-011	②		11-411			12-304			12-417-11	②
	01-024			11-201			11-412			12-305			12-417-12	②

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
		12-417-13			12-821			13-225	○		13-515			③
		12-417-14			12-822			13-226	○		13-516			③
		12-418			12-823			13-227	○		13-601			③
		12-419			12-824			13-301	○		13-602			③
●		12-420			12-825			13-302	○		13-603			③
		12-421			13-001	②		13-303	○		13-604			③
●		12-422	●		13-002	③	●	13-304	○		13-605			③
		12-423			13-003	②		13-305	○		13-606			③
		12-501			13-004	②		13-306	○		13-607			③
		12-502			13-005	②		13-307	○		13-608			③
		12-503			13-006	②		13-308	○		13-609			③
		12-504			13-007			13-309	○		13-610			③
		12-505			13-008			13-310	○		13-611			③
		12-506			13-009			13-311	○		13-612			③
		12-507			13-101			13-312	○		13-613			③
		12-508			13-102			13-313	○		13-614			③
		12-509			13-103			13-314	○		13-615			③
		12-510	●		13-104	③		13-315	○		13-616			③
		12-701			13-105			13-401	○		13-617			③
●		12-702			13-106			13-402	○		13-618			③
●		12-703			13-107			13-403	○		13-619			③
●		12-704			13-108		●	13-404	○		13-620			③
●		12-706			13-109			13-405	○		13-621			③
		12-707			13-110			13-406	○		13-622			③
●		12-708			13-111			13-407	○		13-623			③
●		12-709			13-112			13-408			14-001			②
●		12-710			13-113	②		13-409			14-002			②
●		12-711			13-114			13-410			14-003			②
		12-801			13-115			13-411			14-003-1			②
		12-802			13-116			13-412			14-004			②
		12-803			13-117			13-413			14-005			②
●		12-804			13-201			13-414			14-006			②
●		12-805-1			13-202			13-415			14-007			②
●		12-805-2			13-203			13-416			14-008			②
●		12-805-3	●		13-204	③		13-417			14-009			②
●		12-805-4			13-205		●	13-418			14-009-1			②
●		12-805-5			13-206			13-419			14-010			②
●		12-805-6			13-207			13-420			14-011			②
●		12-805-7			13-208			13-421			14-011-1			②
●		12-805-8			13-209	②		13-422			14-012			②
		12-806			13-210	②		13-423			14-013			②
		12-807			13-211	②	○	13-501			14-014			②
		12-808			13-212	②	○	13-502			14-015			②
		12-809			13-213	②	○	13-503			14-016			②
		12-810			13-214		○	13-504			15-001			②
		12-811			13-215	②	○	13-505						
		12-812			13-216		○	13-506						
		12-813			13-217		○	13-507						
		12-814			13-218		○	13-508						
		12-815			13-219		○	13-509						
		12-816			13-220		○	13-510						
		12-817			13-221		○	13-511						
		12-818			13-222		○	13-512						
		12-819			13-223		○	13-513						
		12-820			13-224		○	13-514						

CONTENTS

	No. of page
GENERAL	01-001
 STRUCTURE AND FUNCTION	
OVERALL STRUCTURE	11-003
ENGINE BODY	11-201
LUBRICATION SYSTEM	11-301
FUEL SYSTEM	11-401
COOLING SYSTEM	11-501
ELECTRICAL SYSTEM	11-801
 TESTING AND ADJUSTING	
GENEAL	12-003
INTAKE AND EXHAUST SYSTEM	12-101
ENGINE BODY	12-201
LUBRICATION SYSTEM	12-301
FUEL SYSTEM	12-401
COOLING SYSTEM	12-501
PERFORMANCE TEST	12-701
TROUBLESHOOTING	12-801
 DISASSEMBLY AND ASSEMBLY	
REQUIRED CAUTIONS FOR DISASSEMBLY AND ASSEMBLY	13-003
GENERAL DISASSEMBLY (4D94-2)	13-101
GENERAL ASSEMBLY (4D94-2)	13-201
GENERAL DISASSEMBLY (3D94-2)	13-301
GENERAL ASSEMBLY (3D94-2)	13-401
GENERAL DISASSEMBLY (4D94-3)	13-501
GENERAL ASSEMBLY (4D94-3)	13-601
 MAINTENANCE STANDARD	 14-001
 REPAIR AND REPLACEMENT OF PARTS	 15-001

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$