

# Shop Manual

ENGINE

**88E -7 SERIES**

**KOMATSU**



# TABLE OF CONTENTS

---

## Structure and Function, Testing and Adjusting, Disassembly and Assembly, and Maintenance Standard

	Page
Introduction .....	1-1
Applicable machine.....	2-1
Safety.....	3-1
General Service Information .....	4-1
Periodic Maintenance .....	5-1
Engine .....	6-1
Fuel System .....	7-1
Cooling System .....	8-1
Lubrication System .....	9-1
Starter Motor .....	10-1
Alternator .....	11-1
Electronic Control System .....	12-1
Electric Wiring .....	13-1
<b>Troubleshooting</b>	
Failure Code (DTC) General Description.....	14-1
Method and Procedure of Failure Diagnosis.....	15-1
Mechanical System Failure Diagnosis .....	16-1

# TABLE OF CONTENTS

---

---

**STRUCTURE AND FUNCTION,  
TESTING AND ADJUSTING,  
DISASSEMBLY AND ASSEMBLY,  
AND MAINTENANCE STANDARD**

---

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$