

# Shop Manual



# D87E-2 D87P-2

## CRAWLER TRACTOR

SERIAL NUMBERS

**D87E-2 - P090001**  
**D87P-2 - P092001**

and UP

This material is proprietary to Komatsu America International Company and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu America International Company

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, periodic revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

# CONTENTS

|           |   |             |
|-----------|---|-------------|
| <b>00</b> | <b>FOREWORD . . . . .</b>                               | <b>00-1</b> |
| <b>01</b> | <b>GENERAL . . . . .</b>                                | <b>01-1</b> |
| <b>10</b> | <b>STRUCTURE AND FUNCTION . . . . .</b>                 | <b>10-1</b> |
| <b>20</b> | <b>TESTING, ADJUSTING AND TROUBLESHOOTING . . . . .</b> | <b>20-1</b> |
| <b>30</b> | <b>DISASSEMBLY AND ASSEMBLY . . . . .</b>               | <b>30-1</b> |
| <b>90</b> | <b>OTHER . . . . .</b>                                  | <b>90-1</b> |

## PRODUCT PUBLICATIONS INFORMATION

Various product Parts and Service Publications are available to all **KOMATSU** construction equipment owners, including operation and maintenance manuals, parts books and service manuals.

Special publications, such as service tool, air conditioning and turbocharger service manuals are also available as well as selected Operation and Service manuals in foreign languages.

The Publications listed below are available for this particular machine(s).

| DESCRIPTION | FORM NUMBER |
|-------------|-------------|
|-------------|-------------|

**PARTS BOOK - PAPER:**

|                                   |            |
|-----------------------------------|------------|
| Chassis and Engine - D87E-2 ..... | BEPB008300 |
| Chassis and Engine - D87P-2 ..... | BEPB008700 |

**OPERATION AND MAINTENANCE MANUAL:**

|                          |            |
|--------------------------|------------|
| Chassis and Engine ..... | CEAM007302 |
|--------------------------|------------|

**SHOP MANUAL**

|               |            |
|---------------|------------|
| Chassis ..... | CEBM004802 |
| Engine .....  | SEBM006409 |

**SAFETY MANUAL**

|                        |         |
|------------------------|---------|
| Machine specific ..... | CLT80-1 |
|------------------------|---------|

Parts and Service Publications can *only* be acquired by authorized KOMATSU distributors using the Komatsu America International Company Parts Inventory Processing System (PIPS).

If the PIPS system is not available at the distributor location, then the following Requisition for Technical Service Publications and Service Forms can be used. Form KDC91E is shown on the reverse side of this page.



**LIST OF ORIGINAL, NEW OR REVISED PAGES**

The affected pages are indicated by using the following marks. It is requested that necessary actions be taken to these pages according to the table below.

Pages w/o marks are previous additions or revised pages.

| Mark | Indication           | Action  |
|------|----------------------|---------|
| ○    | New page to be added | Add     |
| ●    | Page to be replaced  | Replace |
| ( )  | Page to be deleted   | Discard |

**LIST OF ORIGINAL, NEW OR REVISED PAGES**

CEBM004802

| Mark | Page  | Rev |
|------|-------|-----|
| ○    | 1     | ②   |
| ○    | 2     | ②   |
| ○    | 3     | ②   |
| ○    | 4     | ②   |
| ○    | 5     | ②   |
| ○    | 6     | ②   |
| ●    | 00-1  | ②   |
| ●    | 00-2  | ②   |
| ●    | 00-3  | ②   |
| ●    | 00-4  | ②   |
| ●    | 00-5  | ②   |
| ●    | 00-6  | ②   |
| ●    | 00-7  | ②   |
| ●    | 00-8  | ②   |
| ●    | 00-9  | ②   |
| ●    | 00-10 | ②   |
| ●    | 00-11 | ②   |
| ●    | 00-12 | ②   |
| ●    | 00-13 | ②   |
| ●    | 00-14 | ②   |
| ●    | 00-15 | ②   |
| ●    | 00-16 | ②   |
| ●    | 00-17 | ②   |
| ●    | 00-18 | ②   |
| ○    | 00-19 | ②   |
| ○    | 00-20 | ②   |
| ○    | 00-21 | ②   |
| ●    | 01-1  | ②   |
| ●    | 01-2  | ②   |
| ●    | 01-3  | ②   |
| ●    | 01-4  | ②   |
| ●    | 01-5  | ②   |
| ●    | 01-6  | ②   |
| ●    | 01-7  | ②   |
| ●    | 01-8  | ②   |
| ●    | 01-9  | ②   |
| ●    | 01-10 | ②   |
| ○    | 01-11 | ②   |
| ○    | 01-12 | ②   |
| ○    | 01-13 | ②   |
| ○    | 01-14 | ②   |

| Mark | Page  | Rev |
|------|-------|-----|
| ○    | 01-15 | ②   |
| ○    | 01-16 | ②   |
| ●    | 10-1  | ②   |
| ●    | 10-2  | ②   |
| ●    | 10-3  | ②   |
| ●    | 10-4  | ②   |
| ●    | 10-5  | ②   |
| ●    | 10-6  | ②   |
| ●    | 10-7  | ②   |
| ●    | 10-8  | ②   |
| ●    | 10-9  | ②   |
| ●    | 10-10 | ②   |
| ●    | 10-11 | ②   |
| ●    | 10-12 | ②   |
| ●    | 10-13 | ②   |
| ●    | 10-14 | ②   |
| ●    | 10-15 | ②   |
| ●    | 10-16 | ②   |
| ●    | 10-17 | ②   |
| ●    | 10-18 | ②   |
| ●    | 10-19 | ②   |
| ●    | 10-20 | ②   |
| ●    | 10-21 | ②   |
| ●    | 10-22 | ②   |
| ●    | 10-23 | ②   |
| ●    | 10-24 | ②   |
| ●    | 10-25 | ②   |
| ●    | 10-26 | ②   |
| ●    | 10-27 | ②   |
| ●    | 10-28 | ②   |
| ●    | 10-29 | ②   |
| ●    | 10-30 | ②   |
| ●    | 10-31 | ②   |
| ●    | 10-32 | ②   |
| ●    | 10-33 | ②   |
| ●    | 10-34 | ②   |
| ●    | 10-35 | ②   |
| ●    | 10-36 | ②   |
| ●    | 10-37 | ②   |
| ●    | 10-38 | ②   |
| ●    | 10-39 | ②   |
| ●    | 10-40 | ②   |
| ●    | 10-41 | ②   |

| Mark | Page  | Rev |
|------|-------|-----|
| ●    | 10-42 | ②   |
| ●    | 10-43 | ②   |
| ●    | 10-44 | ②   |
| ●    | 10-45 | ②   |
| ●    | 10-46 | ②   |
| ●    | 10-47 | ②   |
| ●    | 10-48 | ②   |
| ●    | 10-49 | ②   |
| ●    | 10-50 | ②   |
| ●    | 10-51 | ②   |
| ●    | 10-52 | ②   |
| ●    | 10-53 | ②   |
| ●    | 10-54 | ②   |
| ●    | 10-55 | ②   |
| ●    | 10-56 | ②   |
| ●    | 10-57 | ②   |
| ●    | 10-58 | ②   |
| ●    | 10-59 | ②   |
| ●    | 10-60 | ②   |
| ●    | 10-61 | ②   |
| ●    | 10-62 | ②   |
| ●    | 10-63 | ②   |
| ●    | 10-64 | ②   |
| ●    | 10-65 | ②   |
| ●    | 10-66 | ②   |
| ●    | 10-67 | ②   |
| ●    | 10-68 | ②   |
| ●    | 10-69 | ②   |
| ●    | 10-70 | ②   |
| ●    | 10-71 | ②   |
| ●    | 10-72 | ②   |
| ●    | 10-73 | ②   |
| ●    | 10-74 | ②   |
| ●    | 10-75 | ②   |
| ●    | 10-76 | ②   |
| ●    | 10-77 | ②   |
| ●    | 10-78 | ②   |
| ●    | 10-79 | ②   |
| ●    | 10-80 | ②   |
| ●    | 10-81 | ②   |
| ●    | 10-82 | ②   |
| ●    | 10-83 | ②   |
| ●    | 10-84 | ②   |
| ●    | 10-85 | ②   |

| Mark | Page   | Rev |
|------|--------|-----|
| ●    | 10-86  | ②   |
| ●    | 10-87  | ②   |
| ●    | 10-88  | ②   |
| ●    | 10-89  | ②   |
| ●    | 10-90  | ②   |
| ●    | 10-91  | ②   |
| ●    | 10-92  | ②   |
| ●    | 10-93  | ②   |
| ●    | 10-94  | ②   |
| ●    | 10-95  | ②   |
| ●    | 10-96  | ②   |
| ●    | 10-97  | ②   |
| ●    | 10-98  | ②   |
| ●    | 10-99  | ②   |
| ●    | 10-100 | ②   |
| ●    | 10-101 | ②   |
| ●    | 10-102 | ②   |
| ○    | 10-103 | ②   |
| ○    | 10-104 | ②   |
| ○    | 10-105 | ②   |
| ○    | 10-106 | ②   |
| ○    | 10-107 | ②   |
| ○    | 10-108 | ②   |
| ○    | 10-109 | ②   |
| ○    | 10-110 | ②   |
| ○    | 10-111 | ②   |
| ○    | 10-112 | ②   |
| ○    | 10-113 | ②   |
| ○    | 10-114 | ②   |
| ○    | 10-115 | ②   |
| ○    | 10-116 | ②   |
| ○    | 10-117 | ②   |
| ○    | 10-118 | ②   |
| ○    | 10-119 | ②   |
| ○    | 10-120 | ②   |
| ○    | 10-121 | ②   |
| ○    | 10-122 | ②   |
| ○    | 10-123 | ②   |
| ○    | 10-124 | ②   |
| ○    | 10-125 | ②   |
| ○    | 10-126 | ②   |
| ○    | 10-127 | ②   |
| ○    | 10-128 | ②   |
| ○    | 10-129 | ②   |

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$