

SHOP MANUAL

PC14R-3 PC14R-3HS PC16R-3 PC16R-3HS

HYDRAULIC EXCAVATOR

SERIAL NUMBER

PC14R-3	F40003	and up
PC14R-3HS	F50003	and up
PC16R-3	F60003	and up
PC16R-3HS	F70003	and up

CONTENTS

	Page
10. STRUCTURE AND FUNCTION	10-1
20. TESTING AND ADJUSTING	20-1
30. DISASSEMBLY AND ASSEMBLY	30-1
90. OTHER	90-1

**PAGE INTENTIONALLY
LEFT BLANK**

REVISED PAGES

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to table below.

Mark	Indication	Action required
○	Page to be newly	Add
●	Page to be replaced	Replace
()	Page to be delete	Discard

Pages having no marks are those previously revised or made additions.

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
	00-1			10-30			20-13			20-67			30-50	
	00-2			10-31			20-14			20-68			30-51	
	00-3			10-32			20-15			20-69			30-52	
	00-4			10-33			20-16			20-70			30-53	
	00-5			10-34			20-17						30-54	
	00-6			10-35			20-18			30-1			30-55	
	00-7			10-36			20-19			30-2			30-56	
	00-8			10-37			20-20			30-3			30-57	
	00-9			10-38			20-21			30-4			30-58	
	00-10			10-39			20-22			30-5			30-59	
	00-11			10-40			20-23			30-6			30-60	
	00-12			10-41			20-24			30-7			30-61	
	00-13			10-42			20-25			30-8			30-62	
	00-14			10-43			20-26			30-9			30-63	
	00-15			10-44			20-27			30-10			30-64	
	00-16			10-45			20-28			30-11			30-65	
	00-17			10-46			20-29			30-12			30-66	
	00-18			10-47			20-30			30-13			30-67	
	00-19			10-48			20-31			30-14			30-68	
	00-20			10-49			20-32			30-15			30-69	
	00-21			10-50			20-33			30-16			30-70	
	00-22			10-51			20-34			30-17			30-71	
	00-23			10-52			20-35			30-18			30-72	
	00-24			10-53			20-36			30-19			30-73	
				10-54			20-37			30-20			30-74	
	10-1			10-55			20-38			30-21			30-75	
	10-2			10-56			20-39			30-22			30-76	
	10-3			10-57			20-40			30-23			30-77	
	10-4			10-58			20-41			30-24			30-78	
	10-5			10-59			20-42			30-25			30-79	
	10-6			10-60			20-43			30-26			30-80	
	10-7			10-61			20-44			30-27			30-81	
	10-8			10-62			20-45			30-28			30-82	
	10-9			10-63			20-46			30-29			30-83	
	10-10			10-64			20-47			30-30			30-84	
	10-11			10-65			20-48			30-31			30-85	
	10-12			10-66			20-49			30-32			30-86	
	10-13			10-67			20-50			30-33			30-87	
	10-14			10-68			20-51			30-34			30-88	
	10-15			10-69			20-52			30-35			30-89	
	10-16			10-70			20-53			30-36			30-90	
	10-17						20-54			30-37			30-91	
	10-18			20-1			20-55			30-38			30-92	
	10-19			20-2			20-56			30-39			30-93	
	10-20			20-3			20-57			30-40			30-94	
	10-21			20-4			20-58			30-41			30-95	
	10-22			20-5			20-59			30-42			30-96	
	10-23			20-6			20-60			30-43			30-97	
	10-24			20-7			20-61			30-44			30-98	
	10-25			20-8			20-62			30-45			30-99	
	10-26			20-9			20-63			30-46			30-100	
	10-27			20-10			20-64			30-47			30-101	
	10-28			20-11			20-65			30-48			30-102	
	10-29			20-12			20-66			30-49			30-103	

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$