

# SHOP MANUAL

---

---

---

# WB91R-5

**BACKHOE-LOADER**

SERIAL NUMBER

**WB91R-5 F00003** and up

**KOMATSU**  
*Utility*



## CONTENTS

	Page
10. STRUCTURE AND FUNCTION.....	10-1
20. TESTING AND ADJUSTMENTS.....	20-1
30. REMOVAL AND INSTALLATION.....	30-1
40. STANDARD MAINTENANCE.....	40-1
90. OTHER.....	90-1

**PAGE INTENTIONALLY  
LEFT BLANK**

## REVISED PAGES

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to table below.

Symbol	Indication	Action required
○	Page to be newly	Add
●	Page to be replaced	Replace
( )	Page to be delete	Discard

Pages having no marks are those previously revised or made additions.

Symbol	Page	Time of revision	Symbol	Page	Time of revision	Symbol	Page	Time of revision	Symbol	Page	Time of revision	Symbol	Page	Time of revision
	00-1			10-30			20-32			30-14			30-68	
	00-2			10-31			20-33			30-15			30-69	
	00-3			10-32			20-34			30-16			30-70	
	00-4			10-33			20-35			30-17			30-71	
	00-5			10-34			20-36			30-18			30-72	
	00-6			10-35			20-37			30-19			30-73	
	00-7			10-36			20-38			30-20			30-74	
	00-8			10-37			20-39			30-21			30-75	
	00-9			10-38			20-40			30-22			30-76	
	00-10			10-39			20-41			30-23			30-77	
	00-11			10-40			20-42			30-24			30-78	
	00-12			10-41			20-43			30-25			30-79	
	00-13			10-42			20-44			30-26			30-80	
	00-14			10-43			20-45			30-27			30-81	
	00-15			10-44			20-46			30-28			30-82	
	00-16			10-45			20-47			30-29			30-83	
	00-17			10-46			20-48			30-30			30-84	
	00-18			10-47			20-49			30-31			30-85	
	00-19			10-48			20-50			30-32			30-86	
	00-20			10-49			20-51			30-33			30-87	
	00-21						20-52			30-34			30-88	
	00-22						20-53			30-35			30-89	
	00-23			20-1			20-54			30-36			30-90	
	00-24			20-2			20-55			30-37			30-91	
				20-3			20-56			30-38			30-92	
	10-1			20-4			20-57			30-39			30-93	
	10-2			20-5			20-58			30-40			30-94	
	10-3			20-6			20-59			30-41			30-95	
	10-4			20-7			20-60			30-42			30-96	
	10-5			20-8			20-61			30-43			30-97	
	10-6			20-9			20-62			30-44			30-98	
	10-7			20-10			20-63			30-45			30-99	
	10-8			20-11			20-64			30-46			30-100	
	10-9			20-12			20-65			30-47			30-101	
	10-10			20-13			20-66			30-48			30-102	
	10-11			20-14			20-67			30-49			30-103	
	10-12			20-15			20-68			30-50			30-104	
	10-13			20-16			20-69			30-51			30-105	
	10-14			20-17			20-70			30-52			30-106	
	10-15			20-18						30-53			30-107	
	10-16			20-19						30-54			30-108	
	10-17			20-20			30-1			30-55			30-109	
	10-18			20-21			30-2			30-56			30-110	
	10-19			20-22			30-3			30-57			30-111	
	10-20			20-23			30-4			30-58			30-112	
	10-21			20-24			30-5			30-59			30-113	
	10-22			20-25			30-6			30-60			30-114	
	10-23			20-26			30-7			30-61			30-115	
	10-24			20-27			30-8			30-62			30-116	
	10-25			20-28			30-9			30-63			30-117	
	10-26			20-29			30-10			30-64			30-118	
	10-27			20-30			30-11			30-65			30-119	
	10-28			20-31			30-12			30-66			30-120	
	10-29						30-13			30-67			30-121	

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$