

Shop Manual

ENGINE

76E -6 SERIES

KOMATSU

ENGINE

76E-6 Series

00 Index and foreword

100 Index

Composition of shop manual	2
Table of contents	3

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Section Title.....	Form Number
Shop Manual, contents binder, binder label and tabs	SEN05334-02
00 Index and foreword	SEN05335-02
100 Index	SEN05336-02
200 Foreword and general information	SEN05337-02
01 Specification	SEN05338-00
100 Specification and technical data.....	SEN05339-00
30 Testing and adjusting	SEN05340-01
101 Testing and adjusting, Part 1.....	SEN05341-00
102 Testing and adjusting, Part 2.....	SEN05342-00
103 Testing and adjusting, Part 3.....	SEN05343-00
104 Testing and adjusting, Part 4.....	SEN05344-00
105 Testing and adjusting, Part 5.....	SEN05345-00
106 Testing and adjusting, Part 6.....	SEN05346-00
107 Testing and adjusting, Part 7.....	SEN05347-01
108 Testing and adjusting, Part 8.....	SEN05348-00
40 Troubleshooting.....	SEN05349-00
100 Troubleshooting of mechanical system.....	SEN05350-00

Table of contents

00 Index and foreword	
100 Index	SEN05336-02
Composition of shop manual	2
Table of contents	3
200 Foreword and general information	SEN05337-02
Introduction.....	2
Applicable machine model and serial number.....	3
Safety Statements	4
Safety Precautions	5
01 Specification	
100 Specification and technical data	SEN05339-00
Component Identification.....	3
Location of Labels	4
Function of Major Engine Components	5
Function of Cooling System Components	7
Diesel Fuel	8
Diesel Fuel Specifications	8
Filling the Fuel Tank	9
Priming the Fuel System	11
Engine Oil.....	12
Engine Oil Specifications.....	12
Service Categories.....	12
Engine Oil Viscosity.....	13
Checking Engine Oil.....	13
Adding Engine Oil	13
Engine Oil Capacity (Typical)	14
Engine Coolant.....	14
Engine Coolant Specifications.....	15
Filling Radiator with Engine Coolant	16
Engine Coolant Capacity (Typical)	16
Specifications	17
Description of Model Number.....	17
Engine Speed Specifications.....	17
Engine General Specifications	18
Principal Engine Specifications	19
Engine Service Information	20
Tightening Torques for Standard Bolts and Nuts	21
Abbreviations and Symbols.....	23
Abbreviations	23
Symbols	23
Unit Conversions	24
Unit Prefixes.....	24
Units of Length	24
Units of Volume	24
Units of Mass.....	24
Units of Force	24
Units of Torque	24
Units of Pressure.....	24
Units of Power	24
Units of Temperature	24

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$