

Shop Manual

TD-7H

TD-8H

TD-9H

CRAWLER TRACTOR

SERIAL NUMBERS TD-7H - P026055
TD-8H - P036255 AND UP
TD-9H - P046275

This material is proprietary to Komatsu America International Company and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu America International Company.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

Copyright 2001 Komatsu
DataKom Publishing Corporation

PRODUCT PUBLICATIONS INFORMATION

VARIOUS PRODUCT PARTS & SERVICE PUBLICATIONS ARE AVAILABLE TO ALL **DRESSER** CONSTRUCTION EQUIPMENT OWNERS, INCLUDING OPERATION AND MAINTENANCE MANUALS, PARTS BOOKS AND SHOP MANUALS.

SPECIAL PUBLICATIONS SUCH AS SERVICE TOOL, AIR CONDITIONING, AND TURBOCHARGER SHOP MANUALS ARE ALSO AVAILABLE AS WELL AS SELECTED OPERATION AND SHOP MANUALS IN FOREIGN LANGUAGES.

THE PUBLICATIONS LISTED BELOW ARE AVAILABLE FOR THESE PARTICULAR MACHINES.

DESCRIPTION	FORM NUMBER
PARTS BOOK - PAPER:	
ENGINE AND CHASSIS - TD7H	BEPB004600
ENGINE AND CHASSIS - TD8H	BEPB004700
ENGINE AND CHASSIS - TD9H	BEPB004800
PARTS BOOK - MICROFICHE:	
ENGINE AND CHASSIS - TD7H	BEPM004600
ENGINE AND CHASSIS - TD8H	BEPM004700
ENGINE AND CHASSIS - TD9H	BEPM004800
OPERATION AND MAINTENANCE MANUAL:	
CHASSIS	CEAM002800
SHOP MANUAL:	
CHASSIS	CEBM003200
ENGINE	SEBM010002
SAFETY MANUAL	CLT80-1

PARTS AND SERVICE PUBLICATIONS CAN ONLY BE ACQUIRED BY AUTHORIZED KOMATSU AMERICA DISTRIBUTORS, USING THE PARTS INVENTORY PROCESSING SYSTEM (PIPS).

IF THE PIPS SYSTEM IS NOT AVAILABLE AT THE DISTRIBUTOR LOCATION, THEN THE FOLLOWING REQUISITION FOR TECHNICAL SERVICE PUBLICATIONS AND SERVICE FORMS CAN BE USED. FORM KDC91D IS SHOWN ON THE REVERSE SIDE OF THIS PAGE.

SECTION INDEX

This shop manual includes information for locations, specifications, service/special tools, tolerances, pressures, lubricants and sealants, special torques, tests and adjustments, assembly tips and service bulletin references for various components of the machine. This shop manual is divided into major sections. These sections are indexed by title and divided by individual section index tab. To use this shop manual, locate the section required and turn to that section index tab.

INTRODUCTION — SECTION 1

MISCELLANEOUS — SECTION 2

— SECTION 4

— SECTION 5

COOLING — SECTION 6

DRIVE TRAIN — SECTION 7

TORQUE CONVERTER — SECTION 7B

TRANSMISSION — SECTION 7C

STEERING DRIVE — SECTION 7E

SPROCKET DRIVE — SECTION 7F

ELECTRICAL — SECTION 8

— SECTION 9

HYDRAULICS — SECTION 10

PUMPS AND MOTORS — SECTION 10A

CONTROL VALVE — SECTION 10B

CYLINDERS — SECTION 10C

— SECTION 11

POWER — SECTION 12

— SECTION 13

UNDERCARRIAGE — SECTION 14

TRACK CHAIN — SECTION 15

MOUNTED EQUIPMENT — SECTION 17

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$