SHOP MANUAL

WB150AVS-2

BACKHOE-LOADER
SERIAL NUMBER
WB150AWS-2 150F80001 and up

This material is proprietary to Komatsu Utility Division and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu Utility Division.

It is our policy to improve our products whenever it is possible and pratical to do so. We reserve the right to make changes or add improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, periodic revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

September 2002

Copyright 2002 Komatsu Utility Division



CONTENTS

		Page
10	STRUCTURE AND FUNCTION	10-1
20	TESTING AND ADJUSTING	20-1
	DIGAGOEMBLY AND ACCEMBLY	
30	DISASSEMBLY AND ASSEMBLY	30-1
4 0	MAINTENANCE STANDARD	4 ∩-1

WB150AWS-2 00-1

PAGE INTENTIONALLY LEFT BLANK The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to table below.

Mark	Indication	Action required			
0	Page to be newly	Add			
•	Page to be replaced	Replace			
()	Page to be delete	Discard			

Pages having no marks are those previously revised or made additions.

LIST OF REVISED PAGES

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
•	00-1	j		10-17			10-58			20-10			20-51	
	00-2			10-18			10-59			20-11			20-52	
	00-2-1			10-19			10-60			20-12			20-53	
	00-2-2	1		10-20			10-61			20-13			20-54	
	00-3			10-21			10-62			20-14			20-55	
	00-4			10-22			10-63			20-15			20-56	
	00-5			10-23			10-64			20-16			20-57	
	00-6			10-24			10-65			20-17			20-58	
	00-7			10-25			10-66			20-18			20-59	
	8-00			10-26			10-67			20-19			20-60	
	00-9			10-27			10-68			20-20			20-61	
	00-10			10-28			10-69			20-21			20-62	
	00-11			10-29			10-70			20-22			20-63	
	00-12			10-30			10-71			20-23			20-64	
	00-13			10-31			10-72			20-24			20-65	
	00-14			10-32			10-73			20-25			20-66	
	00-15			10-33			10-74			20-26			20-67	
	00-16			10-34			10-75			20-27			20-68	
	00-17			10-35			10-76			20-28			20-69	
	00-18			10-36			10-77			20-29			20-70	
	00-19			10-37			10-78			20-30			_	
	00-20			10-38			10-79			20-31		•	30-1 ①)
	00-21			10-39			10-80			20-32			30-2	
	00-22			10-40			10-81			20-33			30-3	
				10-41			10-82			20-34			30-4	
	10-1			10-42			10-83			20-35			30-5	
	10-2			10-43			10-84			20-36			30-6	
	10-3			10-44			10-85			20-37			30-7	
	10-4			10-45			10-86			20-38			30-8	
	10-5			10-46			10-87			20-39			30-9	
	10-6			10-47			10-88			20-40			30-10	
	10-7			10-48						20-41			30-11	
	10-8			10-49			20-1			20-42			30-12	
	10-9			10-50			20-2			20-43			30-13	
	10-10			10-51			20-3			20-44			30-14	
	10-11			10-52			20-4			20-45			30-15	
	10-12			10-53			20-5			20-46			30-16	
	10-13			10-54			20-6			20-47			30-17	
	10-14			10-55			20-7			20-48			30-18	
	10-15			10-56			20-8			20-49			30-19	
	10-16			10-57			20-9			20-50			30-20	

WB150AWS-2

It's a preview. You can download the full file by clicking the link below.

https://shopservicemanual.com/

Service Manuals from 2\$