

SHOP MANUAL

WB93R-5E0

BACKHOE-LOADER

SERIAL NUMBER

WB93R-5E0 F60003 and up

CONTENTS

	Page
10. STRUCTURE AND FUNCTION	10-1
20. TESTING AND ADJUSTING	20-1
30. DISASSEMBLY AND ASSEMBLY	30-1
40. STANDARD MAINTENANCE	40-1
90. OTHER	90-1

**PAGE INTENTIONALLY
LEFT BLANK**

REVISED PAGES

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to table below.

Mark	Indication	Action required
○	Page to be newly	Add
●	Page to be replaced	Replace
()	Page to be delete	Discard

Pages having no marks are those previously revised or made additions.

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
	00-1			10-30			10-84			40-10			40-58	
	00-2			10-31			10-85			40-11			40-59	
	00-3			10-32			10-86			40-12			40-60	
	00-4			10-33			10-87			40-13			40-61	
	00-5			10-34			10-88			40-14			40-62	
	00-6			10-35			10-89			40-15			40-63	
	00-7			10-36			10-90			40-16				
	00-8			10-37			10-91			40-17				
	00-9			10-38			10-92			40-18				
	00-10			10-39			10-93			40-19				
	00-11			10-40			10-94			40-20				
	00-12			10-41			10-95			40-21				
	00-13			10-42			10-96			40-22				
	00-14			10-43			10-97			40-23				
	00-15			10-44			10-98			40-24				
	00-16			10-45			10-99			40-25				
	00-17			10-46			10-100			40-26				
	00-18			10-47			10-101			40-27				
	00-19			10-48			10-102			40-28				
	00-20			10-49			10-103			40-29				
	00-21			10-50			10-104			40-30				
	00-22			10-51			10-105			40-31				
	00-23			10-52			10-106			40-32				
	00-24			10-53			10-107			40-33				
				10-54			10-108			40-34				
	10-1			10-55			10-109			40-35				
	10-2			10-56			10-110			40-36				
	10-3			10-57			10-111			40-37				
	10-4			10-58			10-112			40-38				
	10-5			10-59			10-113			40-39				
	10-6			10-60			10-114			40-40				
	10-7			10-61			10-115			40-41				
	10-8			10-62			10-116			40-42				
	10-9			10-63			10-117			40-43				
	10-10			10-64			10-118			40-44				
	10-11			10-65			10-119			40-45				
	10-12			10-66			10-120			40-46				
	10-13			10-67			10-121			40-47				
	10-14			10-68			10-122			40-48				
	10-15			10-69			10-123			40-49				
	10-16			10-70			10-124			40-50				
	10-17			10-71			10-125			40-51				
	10-18			10-72			10-126			40-52				
	10-19			10-73						40-53				
	10-20			10-74			40-1			40-54				
	10-21			10-75			40-2			40-55				
	10-22			10-76			40-3			40-56				
	10-23			10-77			40-4			40-57				
	10-24			10-78			40-5							
	10-25			10-79			40-6							
	10-26			10-80			40-7							
	10-27			10-81			40-8							
	10-28			10-82			40-9							
	10-29			10-83										

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$