

4206F / 4206R

4208F / 4208R

4212F / 4212R

4406F / 4406R

4408F / 4408R

4412F / 4412R

4416R

Corn Header

SERVICE MANUAL

Part number 47869954

2nd edition English

May 2015

Replaces part numbers 47601951 and 47705757

CASE II
AGRICULTURE

Contents

INTRODUCTION

Hydraulic systems.....	35
[35.910] Head and header hydraulic drive	35.1
[35.603] Deck plate hydraulic system	35.2
[35.660] Flip-up header	35.3
[35.000] Hydraulic systems.....	35.4
Electrical systems	55
[55.000] Electrical system	55.1
[55.100] Harnesses and connectors.....	55.2
[55.421] Feeding control system	55.3
[55.408] Warning indicators, alarms, and instruments	55.4
Attachments/Headers.....	58
[58.130] Attachment/Header frame.....	58.1
[58.120] Attachment/Header feed auger	58.2
[58.220] Corn header structure.....	58.3
[58.218] Corn header feeder structure	58.4
[58.228] Rotating dividers	58.5
[58.230] Stalk choppers	58.6
[58.408] Row-independent header guards and protection	58.7
[58.414] Row-independent header gearboxes	58.8
[58.428] Row-independent header rotating dividers.....	58.9
[58.100] Attachment/Header support and drives	58.10
[58.208] Corn header shields and guards	58.11
[58.224] Header drive	58.12
Product feeding	60
[60.122] Length-of-cut gearbox.....	60.1

Lubrication system..... 71
[71.480] Oiler system..... 71.1



INTRODUCTION

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$