

A8800 MR
Sugar cane harvester
serial PIN PRCY8800HGPA03069 and after

SERVICE MANUAL

Part number 48063439

English

December 2017

© 2017 CNH industrial Latin America LTDA. All Rights Reserved.

CASE IH
AGRICULTURE



SERVICE MANUAL

8800 Multi row [PRCY8800HGPA03069 -]

Link Product / Engine

Product	Market Product	Engine
8800 Multi row [PRCY8800HGPA03069 -]	Middle East Africa	F2CFP613C*H003
8800 Multi row [PRCY8800HGPA03069 -]	Latin America	F2CFP613C*H003
8800 Multi row [PRCY8800HGPA03069 -]	Asia Pacific	F2CFP613C*H003
8800 Multi row [PRCY8800HGPA03069 -]	North America	F2CFP613C*H003
8800 Multi row [PRCY8800HGPA03069 -]	Australia New Zealand	F2CFP613C*H003

Contents

INTRODUCTION

Engine	10
[10.001] Engine and crankcase	10.1
[10.206] Fuel filters	10.2
[10.202] Air cleaners and lines	10.3
[10.254] Intake and exhaust manifolds and muffler	10.4
[10.400] Engine cooling system	10.5
[10.414] Fan and drive	10.6
Transmission	21
[21.900] Hydraulic pump drive.....	21.1
Rear axle system	27
[27.120] Planetary and final drives	27.1
Hydrostatic drive	29
[29.218] Pump and motor components.....	29.1
[29.202] Hydrostatic transmission	29.2
Hydraulic systems	35
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.104] Fixed displacement pump.....	35.3
[35.752] Hydraulic fan drive cooling system.....	35.4
[35.310] Distributor and lines	35.5
[35.965] Chopper control system.....	35.6
[35.370] Tracks suspension hydraulic system.....	35.7
[35.670] Topper hydraulic system	35.8
[35.672] Crop divider hydraulic system.....	35.9
[35.674] Base cutter hydraulic system	35.10

[35.676] Knock-down rollers hydraulic system	35.11
[35.678] Butt lifter roller hydraulic system	35.12
[35.680] Finned roller hydraulic system	35.13
[35.682] Billet elevator hydraulic system	35.14
Tracks and track suspension	48
[48.130] Track frame and driving wheels	48.1
[48.100] Tracks	48.2
[48.138] Track rollers	48.3
[48.110] Front suspension	48.4
Cab climate control	50
[50.200] Air conditioning	50.1
Electrical systems	55
[55.100] Harnesses and connectors	55.1
[55.513] Cab transmission controls	55.2
[55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls	55.3
[55.820] Chopping and cutting control systems	55.4
[55.DTC] FAULT CODES	55.5
Attachments/Headers	58
[58.130] Attachment/Header frame	58.1
Product feeding	60
[60.110] Feeder housing	60.1
[60.340] Topper	60.2
[60.350] Crop divider	60.3
[60.360] Knock-down rollers	60.4
[60.370] Basecutter	60.5
[60.380] Butt lifter roller	60.6
[60.390] Conveyor roller train	60.7
Chopping	64

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$