

# **CX220C**

## **Hydraulic Excavator**

# Service Manual

**Part Number**  
**7111451**  
1<sup>st</sup> Edition  
English 03/2015





# **SERVICE MANUAL**

**CX220C Standard model**

# Link Product / Engine

---

<b>Product</b>	<b>Market Product</b>	<b>Engine</b>
CX220C Modelo padrão	Latin America	F4GE9684E*J615

# Contents

---

## INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase .....	10.1
[10.202] Air cleaners and lines .....	10.2
[10.216] Fuel tanks .....	10.3
[10.254] Intake and exhaust manifolds and muffler .....	10.4
[10.400] Engine cooling system .....	10.5
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.102] Pump control valves.....	35.2
[35.106] Variable displacement pump .....	35.3
[35.300] Reservoir, cooler, and filters.....	35.4
[35.304] Combination pump units .....	35.5
[35.352] Hydraulic swing system .....	35.6
[35.353] Hydraulic travel system .....	35.7
[35.354] Hydraulic central joint .....	35.8
[35.355] Hydraulic hand control .....	35.9
[35.356] Hydraulic foot control.....	35.10
[35.359] Main control valve .....	35.11
[35.736] Boom hydraulic system .....	35.12
[35.737] Dipper hydraulic system.....	35.13
[35.738] Excavator and backhoe bucket hydraulic system.....	35.14
Frames and ballasting .....	39
[39.101] Upper frame .....	39.1
[39.103] Swing ring assembly .....	39.2
[39.140] Ballasts and supports .....	39.3

<b>Tracks and track suspension .....</b>	<b>48</b>
[48.130] Track frame and driving wheels .....	48.1
[48.100] Tracks .....	48.2
[48.134] Track tension units .....	48.3
[48.138] Track rollers .....	48.4
<b>Cab climate control .....</b>	<b>50</b>
[50.100] Heating .....	50.1
[50.200] Air conditioning .....	50.2
<b>Electrical systems .....</b>	<b>55</b>
[55.000] Electrical system .....	55.1
[55.015] Engine control system .....	55.2
[55.036] Hydraulic system control .....	55.3
[55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls .....	55.4
[55.302] Battery .....	55.5
[55.640] Electronic modules .....	55.6
<b>Booms, dippers, and buckets .....</b>	<b>84</b>
[84.910] Boom .....	84.1
[84.100] Bucket .....	84.2
<b>Platform, cab, bodywork, and decals .....</b>	<b>90</b>
[90.116] Fenders and guards .....	90.1
[90.124] Pneumatically-adjusted operator seat .....	90.2
[90.150] Cab .....	90.3

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$