

Shop Manual

BULLDOZER

D155AX-8

SERIAL NUMBERS 100148 and up

KOMATSU

00 INDEX AND FOREWORD

INDEX

00 INDEX AND FOREWORD	00-1
ABBREVIATION LIST	00-4
Before reading the manual - Precautions	00-10
01 SPECIFICATIONS	01-1
CONTENTS	01-2
ABBREVIATION LIST	01-3
SPECIFICATIONS	01-9
SPECIFICATION DRAWING	01-9
SPECIFICATIONS	01-11
WEIGHT TABLE	01-15
10 STRUCTURE AND FUNCTION	10-1
CONTENTS	10-2
ABBREVIATION LIST	10-3
POWER TRAIN SYSTEM	10-9
LAYOUT OF POWER TRAIN SYSTEM	10-9
OPERATION OF POWER TRAIN SYSTEM	10-12
COMPONENT PARTS OF POWER TRAIN SYSTEM	10-13
UNDERCARRIAGE AND FRAME	10-17
MAIN FRAME	10-17
SUSPENSION	10-18
TRACK FRAME AND IDLER CUSHION	10-21
30 TESTING AND ADJUSTING	30-1
CONTENTS	30-2
ABBREVIATION LIST	30-3
UNDERCARRIAGE AND FRAME	30-9
ADJUST IDLER CLEARANCE	30-9
TEST AND ADJUST TRACK TENSION	30-11
50 DISASSEMBLY AND ASSEMBLY	50-1
CONTENTS	50-2
ABBREVIATION LIST	50-3
POWER TRAIN	50-9
REMOVE AND INSTALL FINAL DRIVE ASSEMBLY	50-9
UNDERCARRIAGE AND FRAME	50-16
REMOVE AND INSTALL TRACK FRAME ASSEMBLY	50-16
REMOVE AND INSTALL IDLER ASSEMBLY	50-27
DISASSEMBLE AND ASSEMBLE IDLER ASSEMBLY	50-30
REMOVE AND INSTALL RECOIL SPRING ASSEMBLY	50-35
DISASSEMBLE AND ASSEMBLE RECOIL SPRING	50-38
REMOVE AND INSTALL TRACK ROLLER ASSEMBLY	50-48
REMOVE AND INSTALL CARRIER ROLLER ASSEMBLY	50-51
REMOVE AND INSTALL PIVOT SHAFT ASSEMBLY	50-54
SEPARATION AND CONNECTION OF TRACK ASSEMBLY	50-59
REMOVE AND INSTALL EQUALIZER BAR ASSEMBLY	50-64
DISASSEMBLE AND ASSEMBLE EQUALIZER BAR BUSHINGS	50-70
60 MAINTENANCE STANDARD	60-1
CONTENTS	60-2
ABBREVIATION LIST	60-3
POWER TRAIN	60-9
MAINTENANCE STANDARD OF POWER TRAIN MOUNT	60-9
MAINTENANCE STANDARD OF FINAL DRIVE	60-11
UNDERCARRIAGE AND FRAME	60-14
MAINTENANCE STANDARD OF MAIN FRAME	60-14
MAINTENANCE STANDARD OF SUSPENSION	60-16
MAINTENANCE STANDARD OF TRACK FRAME AND IDLER CUSHION	60-19
MAINTENANCE STANDARD OF IDLER	60-22

MAINTENANCE STANDARD OF TRACK ROLLER FOR CONVENTIONAL TYPE TRACK SHOES	60-24
MAINTENANCE STANDARD OF TRACK ROLLER FOR PLUS TYPE TRACK SHOES	60-26
MAINTENANCE STANDARD OF CARRIER ROLLER FOR CONVENTIONAL TYPE TRACK SHOE.....	60-28
MAINTENANCE STANDARD OF CARRIER ROLLER FOR PLUS TYPE TRACK SHOE	60-30
MAINTENANCE STANDARD OF CONVENTIONAL TYPE TRACK SHOE	60-32
MAINTENANCE STANDARD OF PLUS TYPE TRACK SHOE.....	60-34
MAINTENANCE STANDARD OF SINGLE SHOE AND HEAVY DUTY SHOE	60-36
INDEX.....	1

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$