

580LE-SLE-LSP-LPS 590SLE-LSP LOADER BACKHOES

TABLE OF CONTENTS

DIVISION/SECTION	N° SECTION	REFERENCE N°
1 GENERAL INFORMATION		
Standard Torque Specifications and Loctite Product Chart	1001	7-79450GB
Fluids and Lubricants	1002	7-79461GB
2 ENGINE		
Removing and Installing the Engine and the Radiator	2000	7-79471GB
Stall Tests	2002	7-79482GB
Engine Specifications	2402 *	
Cylinder Head and Valves	2415 *	
Engine Cylinder Block	2425 *	
Lubrication System	2445 *	
Cooling System	2455 *	
Turbocharger	2465 *	
Turbocharger Failure Analysis	2565 *	
3 FUEL SYSTEM		
Fuel System and Filters	3410 *	
Fuel Injector	3413 *	
CAV Injection Pump	3414 *	
Bosch Injection Pump	3415 *	
4 ELECTRICAL SYSTEM		
Removal and Installation of Electrical Components	4000	7-79490GB
Electrical Schematics	4001	7-79503GB
580LSP-590LSP Electronic System and Troubleshooting	4002	7-83511GB
Battery	4003	7-79510GB
Starter Motor	4004	7-79520GB
Instrument Cluster	4005	7-79530GB
Alternator	4007	7-79540GB
5 STEERING		
Removing and Installing the Steering Components	5000	7-79551GB
Steering Specifications, Pressure Checks and Troubleshooting (580LE)	5001	7-79561GB
Steering Specifications, Pressure Checks and Troubleshooting (580SLE)	5001	7-79571GB
Steering Control Valve (Orbitrol), EATON Type	5002	7-79580GB
Rotary Control Valve (Orbitrol), DANFOSS Type	5002	7-27460GB
Steering Cylinders	5003	7-79590GB
Front Axle, Two Wheel Drive Machines	5005	7-79600GB
Front Axle, Four Wheel Drive Machines	5006	7-79611GB

*Refer to the Engine Service Manual

Reprinted

6 TRANSMISSION

Removal and Installation of Transmission Components (CARRARO)	6000	7-27560GB
Removal and Installation of CLARK (Powershift) Transmission	6000	7-27570GB
Transmission Specifications, Pressure Checks and Troubleshooting (CARRARO)	6002	7-79631GB
Transmission Specifications, Pressure Checks and Troubleshooting (CLARK)	6002	7-84330GB
Wheels and Tires	6003	7-79640GB
Rear Axle and Planetaries	6004	7-79650R1GB
Rear Axle and Planetary (Standard).....	6004	7-27300GB
Rear Axle and Planetary (Powershift)	6004	7-27310GB
Gearbox (CARRARO)	6007	7-79660GB
CLARK Powershift Transmission	6007	7-83631GB

7 BRAKES

Removing and Installing the Braking System Components	7000	7-79671GB
Master-Cylinder.....	7003	7-79680GB

8 HYDRAULIC SYSTEM

Removing and Installing the Components of the Hydraulic System.....	8001	7-79690GB
Hydraulic System Specifications, Troubleshooting and Pressure Checks (580LE).....	8002	7-79701GB
Hydraulic System Specifications, Troubleshooting and Pressure Checks (580SLE)	8002	7-79711GB
Cleaning the Hydraulic System	8003	7-79720GB
Hydraulic Pump (580LE)	8004	7-79731GB
Hydraulic Pump (580SLE).....	8004	7-79741GB
Loader Control Valve	8005	7-79751GB
Cylinders	8006	7-79760GB
Backhoe Attachment Control Valve Block (580LE)	8007	7-79771GB
Backhoe Attachment Control Valve Block (580SLE).....	8007	7-79781GB
Auxiliary Control Valve	8008	7-79790GB
Accumulator for Machines Fitted with Ride Control System (Optional)	8009	7-83520GB
Solenoid Valves for Machines Equipped with Ride Control System (Optional)	8010	7-83530GB
Sideshift Carriage Locking Cylinder.....	8011	7-21090GB
Boom Safety Valve	8012	7-27290GB
Dipper Safety Valve	8013	7-27320GB
Loader Arm Safety Valve	8014	7-27330GB
Swing Sequence Valve	8020	7-21010GB

9 CHASSIS/ATTACHMENT

Pedals and Levers	9001	7-79801GB
Air Conditioning Troubleshooting for Systems with R-134a Refrigerant.....	9002	7-79810GB
Air Conditioning Pressure Gauges and Checks for Systems Using R-134a Refrigerant	9003	7-79820GB
Air Conditioning System Maintenance for Systems Using Refrigerant R-134a	9004	7-79830GB
Servicing Components of Air Conditioning System Using R-134a Refrigerant	9005	7-79840GB
Loader	9006	7-79850GB
Cab with ROPS and Safety Frame with ROPS	9007	7-27580GB
Backhoes Attachment	9008	7-79870GB
Seat and Safety Belt	9009	[REDACTED]
Large Format Hydraulic and Electrical Schematics.....	Pocket	[REDACTED]

[REDACTED] Section to be distributed at a later date.

1001

Section

1001

STANDARD TORQUE SPECIFICATIONS AND LOCTITE PRODUCT CHART

Case

Cre 7-79450GB

Copyright © 1996 Case France
Printed in U.K.
Issued March 1996

It's a preview. You can download the full file by
clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$