

MAXXUM® 115 / MAXXUM® 115 Multicontroller / MAXXUM® CVT 115
MAXXUM® 125 / MAXXUM® 125 Multicontroller / MAXXUM® CVT 125
MAXXUM® 135 / MAXXUM® 135 Multicontroller / MAXXUM® CVT 135
MAXXUM® 145 / MAXXUM® 145 Multicontroller / MAXXUM® CVT 145
MAXXUM® 150 / MAXXUM® 150 Multicontroller
Tier 4B (final)
Tractor

SERVICE MANUAL

Part number 47938724

1st edition English

October 2015

CASE II
AGRICULTURE



SERVICE MANUAL

**MAXXUM® 115 Multicontroller , MAXXUM® 115 , MAXXUM® 125
Multicontroller , MAXXUM® 125 , MAXXUM® 135 Multicontroller , MAXXUM®
135 , MAXXUM® 145 Multicontroller , MAXXUM® 145 , MAXXUM® 150
Multicontroller , MAXXUM® 150 , MAXXUM® CVT 115 , MAXXUM® CVT 125 ,
MAXXUM® CVT 135 , MAXXUM® CVT 145**

Link Product / Engine

Product	Market Product	Engine
MAXXUM® CVT 115	North America	F4DFE4134*B005
MAXXUM® CVT 125	North America	F4DFE4133*B007
MAXXUM® CVT 135	North America	F4DFE4132*B005
MAXXUM® CVT 145	North America	F4DFE4131*B007
MAXXUM® 115	North America	F4DFE4134*B006
MAXXUM® 115 Multicontroller	North America	F4DFE4134*B006
MAXXUM® 125	North America	F4DFE4133*B008
MAXXUM® 125 Multicontroller	North America	F4DFE4133*B008
MAXXUM® 135	North America	F4DFE4132*B006
MAXXUM® 135 Multicontroller	North America	F4DFE4132*B006
MAXXUM® 145	North America	F4DFE4131*B008
MAXXUM® 145 Multicontroller	North America	F4DFE4131*B008
MAXXUM® 150	North America	F4DFE6132*B007
MAXXUM® 150 Multicontroller	North America	F4DFE6132*B007

Contents

INTRODUCTION

Engine	10
[10.001] Engine and crankcase	10.1
[10.216] Fuel tanks	10.2
[10.202] Air cleaners and lines	10.3
[10.254] Intake and exhaust manifolds and muffler	10.4
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.5
[10.400] Engine cooling system	10.6
[10.414] Fan and drive	10.7
[10.310] Aftercooler.....	10.8
[10.304] Engine lubrication system.....	10.9
Clutch	18
[18.112] Slip clutch or flywheel damper	18.1
Transmission	21
[21.111] Semi-Powershift transmission	21.1
[21.133] Semi-Powershift transmission external controls	21.2
[21.103] Semi-Powershift transmission lubrication system.....	21.3
[21.152] Semi-Powershift transmission internal components	21.4
[21.504] Continuously Variable Transmission (CVT)	21.5
[21.505] Continuously Variable Transmission (CVT) external controls.....	21.6
[21.506] Continuously Variable Transmission (CVT) lubrication system	21.7
[21.507] Continuously Variable Transmission (CVT) internal components.....	21.8
[21.160] Creeper	21.9
[21.166] Overdrive.....	21.10
Four-Wheel Drive (4WD) system	23
[23.202] Electro-hydraulic control	23.1

[23.314] Drive shaft.....	23.2
Front axle system	25
[25.100] Powered front axle	25.1
[25.102] Front bevel gear set and differential	25.2
[25.108] Final drive hub, steering knuckles, and shafts	25.3
[25.122] Axle suspension control.....	25.4
Rear axle system.....	27
[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential.....	27.2
[27.120] Planetary and final drives	27.3
Power Take-Off (PTO).....	31
[31.104] Rear electro-hydraulic control.....	31.1
[31.114] Two-speed rear Power Take-Off (PTO)	31.2
[31.116] Three-speed rear Power Take-Off (PTO)	31.3
[31.142] Front Power Take-Off (PTO) control	31.4
[31.146] Front Power Take-Off (PTO)	31.5
Brakes and controls	33
[33.202] Hydraulic service brakes	33.1
[33.110] Parking brake or parking lock	33.2
[33.220] Trailer brake hydraulic control.....	33.3
[33.224] Trailer brake pneumatic control	33.4
[33.204] Front axle brake	33.5
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.104] Fixed displacement pump.....	35.3
[35.106] Variable displacement pump	35.4
[35.105] Charge pump.....	35.5

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$