

**W20F**  
Wheel Loader

**SERVICE MANUAL**

Part number 48096018A  
2<sup>nd</sup> edition English  
May 2018

© 2018 CNH Industrial Latin America LTDA. All Rights Reserved.

**CASE**  
CONSTRUCTION



## **SERVICE MANUAL**

**W20F Standard model, with cab, Tier 3, made in Brazil**  
**W20F Fertilizer model, with cab, Tier 3, made in Brazil**

## Link Product / Engine

<b>Product</b>	<b>Market Product</b>	<b>Engine</b>
W20F Standard model, with cab, Tier 3, made in Brazil	Australia New Zealand	F4GE9684T*J601
W20F Standard model, with cab, Tier 3, made in Brazil	North America	F4GE9684T*J601
W20F Standard model, with cab, Tier 3, made in Brazil	Europe	F4GE9684T*J601
W20F Standard model, with cab, Tier 3, made in Brazil	Asia Pacific	F4GE9684T*J601
W20F Standard model, with cab, Tier 3, made in Brazil	Middle East Africa	F4GE9684T*J601
W20F Standard model, with cab, Tier 3, made in Brazil	Latin America	F4GE9684T*J601
W20F Fertilizer model, with cab, Tier 3, made in Brazil	Asia Pacific	F4GE9684T*J601
W20F Fertilizer model, with cab, Tier 3, made in Brazil	Australia New Zealand	F4GE9684T*J601
W20F Fertilizer model, with cab, Tier 3, made in Brazil	Europe	F4GE9684T*J601
W20F Fertilizer model, with cab, Tier 3, made in Brazil	Latin America	F4GE9684T*J601
W20F Fertilizer model, with cab, Tier 3, made in Brazil	North America	F4GE9684T*J601
W20F Fertilizer model, with cab, Tier 3, made in Brazil	Middle East Africa	F4GE9684T*J601

# Contents

---

## INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase .....	10.1
[10.102] Pan and covers .....	10.2
[10.202] Air cleaners and lines .....	10.3
[10.216] Fuel tanks .....	10.4
[10.400] Engine cooling system .....	10.5
Main gearbox and drive .....	14
[14.100] Main gearbox and drive .....	14.1
Transmission.....	21
[21.114] Mechanical transmission .....	21.1
[21.113] Powershift transmission .....	21.2
[21.135] Powershift transmission external controls.....	21.3
[21.155] Powershift transmission internal components.....	21.4
Front axle system .....	25
[25.100] Powered front axle .....	25.1
[25.102] Front bevel gear set and differential .....	25.2
[25.108] Final drive hub, steering knuckles, and shafts .....	25.3
Rear axle system .....	27
[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential .....	27.2
[27.120] Planetary and final drives .....	27.3
[27.124] Final drive hub, steering knuckles, and shafts .....	27.4
Hydrostatic drive .....	29
[29.204] Reservoir, cooler, and lines .....	29.1
[29.218] Pump and motor components.....	29.2

<b>Brakes and controls</b> .....	<b>33</b>
[33.202] Hydraulic service brakes .....	33.1
[33.110] Parking brake or parking lock .....	33.2
<b>Hydraulic systems</b> .....	<b>35</b>
[35.000] Hydraulic systems.....	35.1
[35.102] Pump control valves.....	35.2
[35.106] Variable displacement pump .....	35.3
[35.300] Reservoir, cooler, and filters.....	35.4
[35.359] Main control valve.....	35.5
[35.204] Remote control valves .....	35.6
[35.701] Front loader arm hydraulic system .....	35.7
[35.736] Boom hydraulic system .....	35.8
<b>Frames and ballasting</b> .....	<b>39</b>
[39.100] Frame .....	39.1
<b>Steering</b> .....	<b>41</b>
[41.200] Hydraulic control components.....	41.1
[41.206] Pump .....	41.2
[41.216] Cylinders .....	41.3
[41.101] Steering control .....	41.4
<b>Wheels</b> .....	<b>44</b>
[44.520] Rear wheels.....	44.1
[44.511] Front wheels.....	44.2
<b>Cab climate control</b> .....	<b>50</b>
[50.104] Ventilation .....	50.1
[50.200] Air conditioning .....	50.2
<b>Electrical systems</b> .....	<b>55</b>
[55.000] Electrical system .....	55.1

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$