

SERVICE MANUAL

PI030 / PI040 / PI050 / PI060

Air Cart

Part number 84329246

3rd edition English

March 2014

Replaces part number 87478740



Contents

INTRODUCTION

Rear axle system.....	27
[27.550] Non-powered rear axle.....	27.1
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.744] Seeding hydraulic circuit.....	35.3
[35.748] Metering system hydraulic circuit.....	35.4
[35.912] Hydraulic seeding fan system.....	35.5
Wheels.....	44
[44.520] Rear wheels.....	44.1
[44.901] Caster wheels.....	44.2
Electrical systems.....	55
[55.000] Electrical system.....	55.1
[55.100] Harnesses and connectors.....	55.2
[55.301] Alternator.....	55.3
[55.404] External lighting.....	55.4
[55.516] Seeding control system.....	55.5
[55.517] Cab seeding controls.....	55.6
[55.545] Auger.....	55.7
[55.640] Electronic modules.....	55.8
[55.954] Split meter control system.....	55.9
[55.DTC] FAULT CODES.....	55.10
Metering system.....	61
[61.800] Split meter control system.....	61.1
[61.901] Metering mechanical drive.....	61.2

[61.904] Product metering	61.3
Seeding	77
[77.100] Product handling and delivery drive system	77.1
[77.101] Seeding fan system	77.2
[77.904] Air distribution system	77.3



INTRODUCTION

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$