

**435 - 445
Skid Steer Loader
445CT
Compact Track
Loader
Repair Manual
Bur 6-75491**

6-75491SL

CASE

REPAIR MANUAL



**435
445CT
445**

Contents

INTRODUCTION	
DISTRIBUTION SYSTEMS	A
POWER PRODUCTION	B
POWER TRAIN	C
TRAVELLING	D
BODY AND STRUCTURE	E
WORKING ARM	H
TOOLS AND COUPLERS	J



INTRODUCTION

Contents

INTRODUCTION

Basic instructions (- A.90.A.05) 435, 445, 445CT	3
Torque (- A.90.A.10) 435, 445	7
Consumables (- A.92.A.55) 435, 445, 445CT	11
Conversion factors (- A.92.A.21) 435, 445, 445CT	15

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$