
JX55, JX65, JX75, JX85, JX95 REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL	2
SECTION 10 - ENGINE	2
SECTION 18 - CLUTCH	5
SECTION 21 - FRONT TRANSMISSION	7
SECTION 23 - MFD TRANSFER BOX	8
SECTION 25 - MFD AXLE	10
SECTION 27 - REAR TRANSMISSION	12
SECTION 31 - POWER TAKE-OFF	13
SECTION 33 - BRAKES	14
SECTION 35 - HYDRAULIC SYSTEMS	15
SECTION 41 - STEERING	17
SECTION 44 - FRONT AXLE AND WHEELS (2WD)	18
SECTION 55 - ELECTRICAL SYSTEM	21
SECTION 90 - PLATFORM, CAB, BODYWORK AND DECALS	27

The following pages are the collation of the contents pages from each section and chapter of the JX Tractor Repair manual. Complete Repair part # 87060401.

The sections used through out all Case IH product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the JX Tractors.

SECTION 00 - GENERAL

BOOK 1 - 87060402

Chapter 1 - General

CONTENTS

Section	Description	Page
	General Instructions	3
	Health and Safety	5
	Precautionary Statements	15
	Safety	16
	Ecology and the Environment	19
	Minimum Hardware Tightening Torques	20
	Federal Emissions Warranty	22
	California Emission Control Warranty Statement	23
	Consumables	25

SECTION 10 - ENGINE

BOOK 1 - 87060402

Chapter 1 - Engines Before PIN HFJ013287

CONTENTS

Section	Description	Page
	Specifications	3
	Tightening Torques	14
	Special Tools	15
	Troubleshooting	25
	Overhaul	29
	Engine	29
	Removal	29
	Installation	41
	Compression Test	43
	Compression Ratio	43
	Disassembly	44
	Assembly	59
	Checks, Dimensions and Repairs	69

SECTION 10 - ENGINE

BOOK 1 - 87060402

Chapter 1 - Engines Before PIN HFJ013287 (Continued)

CONTENTS

Section	Description	Page
	Cylinder Block and Liners	69
	Crankshaft, Main Bearings and Flywheel	71
	Connecting Rods	75
	Pistons	76
	Camshaft, Tappets and Valves	79
	Cylinder Head	82
	Rotating Counterweight Dynamic Balancer (JX75, JX85, and JX95 Models)	83
	Engine Lubrication Components	84
	Oil Pump	84
	Oil Filter	85
	Low Oil Pressure Indicator	85
	Cooling System	85
	Radiators	85
	Valve Guides	86
	Valve Seats in Cylinder Head	89
	Crankshaft Front Oil Seal	90
	Removal	90
	Installation	95
	Valve Clearance	96
	Adjustment	96
	Coolant Pump and Alternator Drive Belt	99
	Tension Adjustment	99
	Water Pump	100
	Removal	100
	Disassembly	103
	Assembly	103
	Installation	104
	Cooling System Thermostat	104
	Removal	104
	Installation	107
	Radiator	108
	Removal	108
	Installation	111

SECTION 10 - ENGINE

BOOK 1 - 87060402

Chapter 2 - Fuel Injection on Engines Before PIN HFJ013287

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	4
	Special Tools	4
	Injector Sleeves	5
	Checking Injector Protrusion	5
	Removal	5
	Installation	5
	Fuel Injectors	7
	Removal	7
	Installation	8
	Bosch Injection Pump	9
	Removal	9
	Installation	13
	Timing	14
	Air Bleeding	16

SECTION 10 - ENGINE

BOOK 1 - 87060402

Chapter 3 - Engines After PIN HFJ013287 (Tier II Emissionized)

CONTENTS

Section	Description	Page
	Specifications	3
	Tightening Torques	15
	Special Tools	16
	Sectional Views and Diagrams	20
	Troubleshooting	27

SECTION 10 - ENGINE

BOOK 1 - 87060402

Chapter 3 - Engines After PIN HFJ013287 (Tier II Emissionized) (Continued)

CONTENTS

Section	Description	Page
	Overhaul	31
	Engine	31
	Removal	31
	Installation	43
	Disassembly	45
	Assembly	60
	Compression Test	70
	Checks, Dimensions and Repairs	71
	Cylinder Block and Liners	71
	Crankshaft, Main Bearings and Flywheel	73
	Connecting Rods	77
	Pistons	78
	Camshaft, Tappets and Valves	81
	Cylinder Head	84
	Rotating Counterweight Dynamic Balancer (JX75, JX85 and JX95 models)	85
	Engine Lubrication Components	86
	Oil Pump	86
	Oil Filter	87
	Low Oil Pressure Indicator	87
	Cooling System	87
	Radiator	87
	Valve Guides	88
	Valve Seats in Cylinder Head	91
	Crankshaft Front Oil Seal	92
	Removal	92
	Installation	97
	Valve Clearance	98
	Adjustment	98
	Engine Component Overhaul	101
	Coolant Pump and Alternator Drive Belt	101
	Tension Adjustment	101
	Water Pump	102

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$