

SERVICE MANUAL

L213 / L216 Tier 4B (final) 200 Series Skid Steer Loader

*L213 PIN NDM458999 and above
L216 PIN NDM477925 and above*

ENGINE - 10
FRONT AXLE SYSTEM - 25
REAR AXLE SYSTEM - 27
HYDROSTATIC DRIVE - 29
BRAKES AND CONTROLS - 33

Part number 47720730

English

April 2014

Replaces part number 47571183, 47571184



**200 SERIES
SKID STEER LOADER
SERVICE**

**L213 / L216
TIER 4B (final)**

*L213 PIN NDM458999 and above
L216 PIN NDM477925 and above*

**Vol. I
47712044**



**200 SERIES
SKID STEER LOADER
SERVICE**

**L213 / L216
TIER 4B (final)**

*L213 PIN NDM458999 and above
L216 PIN NDM477925 and above*

**Vol. I
47712044**



L213 / L216 TIER 4B (FINAL) 200 SERIES SKID STEER LOADER

*L213 PIN NDM458999 and above
L216 PIN NDM477925 and above*

SERVICE MANUAL COMPLETE CONTENTS

COMPLETE SERVICE MANUAL	47712044
BOOK 1	47720730
Engine – 10	
Front axle system – 25	
Rear axle system – 27	
Hydrostatic drive – 29	
Brakes and controls – 33	
BOOK 2	47720731
Hydraulic systems – 35	
Frames and ballasting – 39	
Wheels - 44	
Cab climate control – 50	
Electrical systems – 55	
BOOK 3	47720732
Electrical systems – 55	
BOOK 4	47720733
Electrical systems – 55	
BOOK 5	47720734
Electrical systems – 55	
Front loader and bucket - 82	
Platform, cab, bodywork, and decals – 90	
COMPLETE CONTENTS	47720735
BINDER SPINE	47720736
ELECTRICAL SCHEMATIC POSTERS	47547372 47547374
HYDRAULIC SCHEMATIC POSTER	47551846
ENGINE SERVICE MANUAL (sold separately)	47434934

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.414] Fan and drive	10.2
[10.501] Exhaust Gas Recirculation (EGR) - Diesel Particulate Filter (DPF) exhaust treatment	10.3
Front axle system	25
[25.450] Chain drive system.....	25.1
Rear axle system.....	27
[27.650] Chain drive system	27.1
Hydrostatic drive.....	29
[29.202] Hydrostatic transmission	29.1
[29.200] Mechanical control	29.2
[29.218] Pump and motor components.....	29.3
Brakes and controls	33
[33.110] Parking brake or parking lock	33.1
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.104] Fixed displacement pump.....	35.2
[35.128] Auxiliary hydraulic function control	35.3
[35.300] Reservoir, cooler, and filters.....	35.4
[35.350] Safety and main relief valves	35.5
[35.359] Main control valve.....	35.6
[35.701] Front loader arm hydraulic system	35.7
[35.723] Front loader bucket hydraulic system.....	35.8
[35.724] Front loader hydraulic system control.....	35.9

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$