

**SERVICE
MANUAL**

**RG140.B
RG170.B
RG200.B
RG140.B VHP
RG170.B VHP
RG200.B VHP
RG170.B AWD
RG200.B AWD**
GRADERS

I/I

Printed in Brazil
Copyright © 2012 – CNH Latin America LTDA.
All Rights Reserved.

Part Number
71114389
03/2012
1st Edition

SERVICE MANUAL

**RG140.B / RG170.B / RG200.B
RG140.B VHP / RG170.B VHP / RG200.B VHP
RG170.B AWD / RG200.B AWD**
GRADERS

I/I

Part Number 71114389
03/2012
1st Edition





Graders

RG140.B / RG170.B / RG200.B
RG140.B VHP / RG170.B VHP / RG200.B VHP
RG170.B AWD / RG200.B AWD
TIER 0 / TIER 1 / TIER 2 / TIER 3

Service Manual

71114389



GRADERS
RG140.B / RG170.B / RG200.B
RG140.B VHP / RG170.B VHP / RG200.B VHP
RG170.B AWD / RG200.B AWD

Service Manual

71114389

Table of Contents

Description	Section Number	Publication Form Number
General		
Section Index - General	Tab 1	6-46520
Standard Torque Especifications	1001	6-46530
Fluids and Lubricants	1002	6-46540
Metric Conversion Chart	1003	6-46550
Service Tools	1005	6-46551
Engine		
Section Index – Engines	Tab 2	6-46559
Engine	2000	6-46441
Charge Air Cooler System	2003	6-46570
Fuel System		
Section Index - Fuel System	Tab 3	6-46580
Fuel System	3001	6-46590
Electrical		
Section Index - Electrical	Tab 4	6-46600
Removal and Installation of Starter and Alternator	4001	6-42320
Electrical Diagram – Models Without All Wheel Drive System	4002	6-46620
Electrical Diagram – Models With All Wheel Drive System	4003	6-46621
Battery	4004	6-42330
Alternator – 80 Ampere	4008	6-42361
Steering		
Section Index - Steering	Tab 5	6-46770
Front Wheel, Axle and Wheel Lean	5002	6-46780
Steering Control Valve – RG140.B VHP / RG170.B VHP / RG200.B VHP / RG170.B AWD / RG200.B AWD Models	5003	6-46690

Description	Section Number	Publication Form Number
Steering Priority Valve – RG140.B VHP / RG170.B VHP / RG200.B VHP / RG170.B AWD / RG200.B AWD Models	5004	6-46700
Power Train		
Section Index - Power Train	Tab 6	6-46720
ZF Transmission – Ergopower 5/6 WG-160 – RG140.B / RG170.B / RG140.B VHP / RG170.B VHP Models	6000	6-46730
FUNK Transmission – Specifications, Pressure Checks, Troubleshooting – RG140.B VHP / RG170.B VHP Models	6002	6-46750
FUNK Transmission – RG140.B VHP / RG170.B VHP / RG170.B AWD Models	6003	6-75360
FUNK Transmission – RG200.B / RG200.B VHP / RG200.B AWD Models	6004	6-75361
Front Axle – RG140.B / RG170.B / RG200.B / RG140.B VHP / RG170.B VHP / RG200.B VHP Models	6007	6-46790
Front Drive Axle – RG170.B AWD / RG200.B AWD Models	6008	6-46770
Transmission Gear Box (Wheel Reductor) For Front Drive Axle – RG170.B AWD / RG200.B AWD Models	6009	6-46771
Rear Axle Assembly (Graziano) – RG140.B / RG140.B VHP Models	6010	6-46820
Rear Axle Assembly (Graziano) – RG170.B / RG170.B VHP / RG170.B AWD / RG200.B / RG200.B VHP / RG200.B AWD Models	6011	6-46811
Tandem for Rear Axle Assembly (Graziano)	6013	6-46821
Tandem Flange Adjustments (Graziano)	6014	6-46822
Brakes		
Section Index – Brakes	Tab 7	6-46810
Hydraulic Brake Troubleshooting	7002	6-46830
Brake Pedal Valve and System	7003	6-46840
Hydraulics		
Section Index - Hydraulics	Tab 8	6-46812
Removal and Installation of Hydraulic Components	8001	6-46870
Front Wheel Drive Hydraulic Pump and Motor – RG170.B AWD / RG200.B AWD Models	8003	6-46890
Hydraulic Schematics – RG170.B AWD / RG200.B AWD Models	8004	6-46891
Mounted Equipment		
Section Index - Mounted Equipment	Tab 9	6-46940
Air Conditioning Troubleshooting and System Checks for Systems With HFC-134A Refrigerant	9002	6-46950
Air Conditioner System Service	9003	6-46960
Removal and Installation of Air Conditioning Components for Systems With HFC-134A Refrigerant	9004	6-46971
Rear Ripper	9007	6-47011
Frame, Articulation Joint Circle and Scarifier	9008	6-47001
Front Blade and Counterweight	9009	6-47021
ROPS Cab	9010	6-47031
Cab Glass Installation	9011	6-47041

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$