

SERVICE MANUAL

T3.60F / T3.70F / T3.80F
Tractor

Part number 51517507

English
July 2018





SERVICE MANUAL

**T3.60F
T3.70F
T3.80F**

Link Product / Engine

Product	Market Product	Engine
T3.60F	Middle East Africa	8035.25A IIIB
T3.60F	Europe	8035.25A IIIB
T3.70F	Europe	8035.25B IIIB
T3.70F	Middle East Africa	8035.25B IIIB
T3.80F	Middle East Africa	8035.25C IIIB
T3.80F	Europe	8035.25C IIIB

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
Clutch	18
[18.110] Clutch and components	18.1
Transmission.....	21
[21.114] Mechanical transmission	21.1
[21.130] Mechanical transmission external controls.....	21.2
[21.112] Power shuttle transmission.....	21.3
[21.120] Gearbox.....	21.4
[21.160] Creeper	21.5
Four-Wheel Drive (4WD) system	23
[23.101] Mechanical control	23.1
[23.202] Electro-hydraulic control	23.2
[23.314] Drive shaft.....	23.3
Front axle system	25
[25.100] Powered front axle	25.1
[25.102] Front bevel gear set and differential	25.2
[25.108] Final drive hub, steering knuckles, and shafts	25.3
Rear axle system.....	27
[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential	27.2
[27.120] Planetary and final drives	27.3
Hydrostatic drive.....	29
[29.300] Rear hydrostatic transmission.....	29.1
Power Take-Off (PTO).....	31

[31.101] Rear mechanical control	31.1
[31.225] Clutches	31.2
Brakes and controls	33
[33.202] Hydraulic service brakes	33.1
[33.110] Parking brake or parking lock	33.2
[33.220] Trailer brake hydraulic control.....	33.3
Hydraulic systems.....	35
[35.525] Auxiliary hydraulic valves and lines	35.1
[35.100] Main lift system.....	35.2
[35.162] Front hitch cylinders and lines	35.3
Steering.....	41
[41.101] Steering control	41.1
[41.216] Cylinders	41.2
Wheels	44
[44.511] Front wheels.....	44.1
Electrical systems	55
[55.000] Electrical system	55.1
[55.100] Harnesses and connectors.....	55.2
[55.201] Engine starting system	55.3
[55.301] Alternator	55.4
[55.302] Battery.....	55.5
[55.013] Engine oil system	55.6
[55.512] Cab controls.....	55.7
[55.408] Warning indicators, alarms, and instruments	55.8
[55.DTC] FAULT CODES.....	55.9
Platform, cab, bodywork, and decals	90
[90.110] Operator platform less cab	90.1

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$