



TOURING MODELS

2008 HARLEY-DAVIDSON® PARTS CATALOG

GENERAL INFORMATION

2008 TOURING MODELS PARTS CATALOG

THIS IS NOT AN ASSEMBLY MANUAL AND SHOULD NOT BE USED AS SUCH

About This Manual

This Parts Catalog has been prepared to make it easier for you to order parts for the 2008 Touring model motorcycles. You will also find a complete Hardware Listing at the back of the book for your convenience. The numbers shown in the illustrations correspond to the numbers in the "INDEX NO." column in the parts lists. Please consult the illustrations when ordering parts to ensure you receive all the required parts. Take note that the number in parenthesis following the part description is the quantity of that part needed for complete assembly; if there is no number in parenthesis, only one is used. Prices of parts in this catalog are published separately.

The following instructions should be followed carefully when ordering parts:

- The "MODELS" column in the parts lists may include one or more two-character codes that correspond to the V.I.N. model designations. The Touring models and their respective two-character codes are listed at the bottom of each right-hand page for your reference. If a part fits all Touring models, "All" will be in the corresponding "MODEL" column.
- Be sure to specify the correct part number for each item. The part numbers appear under the "PART NO." column in the parts lists.
- Orders may be placed via your computer for all parts. Please review your system documentation for details on placing orders electronically. All non-warranty replacement crankcase orders require return of the complete left crankcase half with V.I.N.. All non-warranty replacement frame orders require return of the steering neck with V.I.N.. Non-compliance will result in a fine. See non-warranty frame and crankcase policy or contact your SPOC team for details.
- Parts marked **"105 ANNIVERSARY RESTRICTED SALE PART"** are limited edition items and can only be ordered as direct replacements. Harley-Davidson may require that certain "RESTRICTED SALE PART" items be returned.
- The sale or use of these parts or accessories does not grant the purchaser a license or other right under any Harley-Davidson patent.
- For all 2008 and later painted parts refer to the Service Section of h-dnet.com which features a listing of painted part numbers for all Harley-Davidson motorcycles.

To the best knowledge of Harley-Davidson Motor Company, the material contained herein is accurate as of the date this publication was approved for printing. Harley-Davidson Motor Company reserves the right to change specifications, equipment, or designs at any time without notice and without incurring obligation.

Vehicle Identification Number (V.I.N.)

See Figure 1 on the next page. The full 17-digit serial, or V.I.N., is stamped on the right side of the frame backbone at the rear of the steering head (under the main harness). The V.I.N. is also printed on a label on the left side of the steering head.

An abbreviated V.I.N. is stamped on the left side crankcase between the front and rear cylinders.

Sample V.I.N. as it appears on the steering head - **1HD1FC4138Y600041**

Sample abbreviated V.I.N. as it appears on the left crankcase - **FC48600041**

Always give the full 17-digit V.I.N. when ordering parts or making any inquiry about your motorcycle.

① ② ③ ④ ⑤ ⑥ ⑦ ⑧ ⑨ ⑩
1 HD 1 FC 4 1 3 8 Y 600041

Figure 1. Typical Harley-Davidson V.I.N.: 2008 Touring Models

Table 1. Harley-Davidson V.I.N. Breakdown: 2008 Touring Models

1	Market designation	1=Originally manufactured for sale within the United States 5=Originally manufactured for sale outside of the United States
2	Manufacturer	HD=Harley-Davidson
3	Motorcycle type	1=Heavyweight motorcycle (901 cc or larger)
4	Model	See V.I.N. model table
5	Engine type	4=Twin Cam 96™, 1584 cc air cooled, fuel injected
6	Introduction date	1=Regular 2=Mid-year 3=California/regular 4=Cosmetic changes and/or special introductory date 5=California/cosmetic changes and/or special introductory date 6=California/mid-year
7	V.I.N. check digit	Can be 0-9 or X
8	Model year	8=2008
9	Assembly plant	Y=York, PA U.S.A.
10	Sequential number	Varies

Table 2. V.I.N. Model Codes: 2008 Touring Models

FB	FLHR Road King®	FC	FLHTCU Ultra Classic® Electra Glide®
FG	FLHTCU Ultra Classic® Electra Glide® with sidecar	FL	FLHTCU Ultra Classic® Electra Glide® Shrine
FS	FLTR Road Glide®	FV	FLHT Electra Glide® Standard
FF	FLHTC Electra Glide® Classic	KB	FLHX Street Glide™
FW	FLHR Road King® Shrine	FR	FLHRC Road King® Classic

©2008 H-D.

ALPHABETICAL INDEX

PART DESCRIPTION	PAGE
ABS BRAKE MODULE.....	61
ABS BRAKES - FRONT.....	53
ABS BRAKES - REAR.....	61
ACTIVE INTAKE & EXHAUST.....	135
AIR CLEANER.....	23
AIR CLEANER COVER.....	23
ALTERNATOR & REGULATOR.....	25
AMPLIFIER - SIDE CAR.....	241
ANTENNA.....	197
AUDIO HARNESS.....	201
BATTERY.....	137
BATTERY, TRAY & CABLES.....	137
BATTERY CABLE.....	137
BATTERY TRAY.....	137
BELT - REAR 137T.....	47
BELTS, CHAINS, & SPROCKETS.....	47
BRAKE DISC - FRONT.....	57
BRAKE DISC - REAR.....	65
BRAKE LEVER - FRONT.....	49
BRAKE LEVER - REAR.....	59
BRAKELINE FRONT - NON-ABS.....	51
BRAKELINE REAR - NON-ABS.....	59
BRAKES - FRONT.....	55
BRAKES - REAR.....	63
BREATHER - FILTER.....	11
BREATHER - GASKET KIT.....	11
BUMPER - FRONT.....	113
C.B. & INTERCOM CONTROL POD.....	203
CABLE, CONTROL - EXHAUST VALVE.....	135
CAM SERVICE GASKET KIT.....	11
CAMSHAFTS & CAM COVER - TWIN CAM 96™.....	17
CAM SUPPORT ASSEMBLY.....	17
CB MODULE.....	197
CHAIN - PRIMARY.....	47
CLUTCH.....	41
CLUTCH CONTROL.....	45
COIL.....	27
COVER ROCKER ARMS.....	11
CRANKCASE.....	15
CRANKCASE & ENGINE OIL FILTER - TWIN CAM 96™.....	15
CRUISE CONTROL.....	95
CYLINDERS, HEADS, & VALVES - TWIN CAM 96™.....	9
DEFLECTOR - DEBRIS.....	47
DIPSTICK.....	37
ECM.....	27
ELECTRONIC CONTROL MODULE (ECM) & COIL.....	27
ENGINE ASSEMBLY - TWIN CAM 96™.....	7
ENGINE - COMPLETE.....	7
ENGINE GUARD.....	73
ENGINE MOUNTS & STABILIZER LINKS.....	19
ENGINE SENSORS & SWITCHES.....	29
EVAPORATIVE EMISSIONS COMPONENTS.....	247
EXHAUST ACTUATOR.....	135
EXHAUST SYSTEM.....	133
FAIRING - FLHT, FLHX.....	93
FAIRING LOWERS - ULTRA.....	105
FENDER - FRONT.....	111
FENDER - REAR.....	115

PART DESCRIPTION	PAGE
FILTER - ENGINE AIR.....	23
FILTER - FUEL.....	121
FILTER - FUEL.....	127
FLYWHEEL.....	13
FOOTBOARDS & FOOTPEGS.....	79
FRAME, REAR FORK, & JIFFY STAND (1 OF 2).....	73
FRAME, REAR FORK, & JIFFY STAND (2 OF 2).....	75
FRONT BRAKE CALIPER.....	55
FRONT BRAKE LINE - NON-ABS.....	51
FRONT BRAKE LINES - ABS.....	53
FRONT BRAKE MASTER CYLINDER.....	49
FRONT FENDER (1 OF 2).....	111
FRONT FENDER (2 OF 2).....	113
FRONT FORK - BRACKETS.....	67
FRONT FORK - LEFT & RIGHT (FAIRING).....	71
FRONT FORK - LEFT & RIGHT (NON-FAIRING).....	69
FRONT WHEEL.....	57
FUEL INDUCTION MODULE.....	21
FUEL INJECTOR.....	21
FUEL PUMP - FLHR & FLHRC.....	127
FUEL PUMP - FLHT, FLHTC, FLHTCU, FLHX & FLTR.....	121
FUEL TANK CONSOLE - FLHT, FLHTC, FLHTCU, FLHX & FLTR.....	123
FUEL TANK - FLHR & FLHRC.....	125
FUEL TANK - FLHT, FLHTC, FLHTCU, FLHX & FLTR.....	119
FUEL TANK INSTRUMENTS - FLHR & FLHRC.....	141
FUEL TANK TRIM (1 OF 2).....	129
FUEL TANK TRIM (2 OF 2).....	131
FUSE - 15 AMP.....	161
FUSE - 15 AMP.....	171
FUSE - 15 AMP.....	181
FUSE - 15 AMP.....	191
FUSE - 30 AMP.....	173
FUSE - 30 AMP.....	193
FUSE - 30 AMP.....	243
FUSE-MAXI 40 AMP.....	161
FUSE-MAXI 40 AMP.....	171
FUSE-MAXI 40 AMP.....	181
FUSE-MAXI 40 AMP.....	191
GASKET KITS.....	9
GASKET KITS.....	17
GAUGE - AIR TEMP - FLHT.....	139
GAUGE - AIR TEMP - FLHX.....	139
GAUGE - AIR TEMP - FLTR.....	99
GAUGE - FUEL - FLHR/C.....	141
GAUGE - FUEL - FLHT.....	139
GAUGE - FUEL - FLHX.....	139
GAUGE - FUEL - FLTR.....	99
GAUGE - OIL PRESSURE - FLHX.....	139
GAUGE - VOLTMETER - FLHT.....	139
GAUGE - VOLTMETER - FLHX.....	139
GAUGE - VOLTMETER - FLTR.....	99
GEAR SHIFTER.....	33
HANDLEBAR.....	89
HANDLEBAR GRIPS.....	91
HANDLEBAR SWITCHES - LEFT.....	205
HANDLEBAR SWITCHES - RIGHT.....	207
HARNESS, BANK ANGLE SENSOR.....	235
HEAD, CYLINDER.....	9

ALPHABETICAL INDEX

PART DESCRIPTION	PAGE	PART DESCRIPTION	PAGE
HEADLAMP - FLHR.....	107	MASTER CYLINDER - REAR.....	59
HEADLAMP - FLHT, FLHX.....	93	MASTER CYLINDER - SIDECAR.....	227
HEADLAMP - FLTR.....	97	MEDALLION - FUEL TANK.....	129
HEADSET - SOUND SYSTEM.....	199	MIRRORS.....	219
HORN.....	147	MODULE - INDUCTION.....	21
HYDRAULIC LIFTERS.....	11	MUFFLER.....	133
IGNITION SWITCH.....	209	NACELLE & HEADLAMP - FLHR & FLHRC.....	107
INDICATOR LAMPS - FLHR/C.....	141	OIL PAN - TRANSMISSION.....	37
INDICATOR LAMPS - FLHT, FLHX.....	139	OIL PRESSURE GAUGE - FLTR.....	99
INNER FAIRING - FLHT/C/CU & FLHX.....	95	OIL PRESSURE SENDER.....	29
INNER FAIRING - FLTR.....	99	OIL PUMP ASSEMBLY.....	17
INNER TUBE - FRONT.....	57	PASSING LAMPS & FRONT TURN SIGNALS.....	109
INNER TUBE - REAR.....	65	PISTON COOLING JETS.....	15
INSTRUMENTS - FLHT, FLHTC, FLHTCU & FLHX.....	139	PISTONS & FLYWHEEL ASSEMBLY - TWIN CAM 96™.....	13
INTERCOM CONSOLE.....	203	PRIMARY COVER.....	43
JIFFY STAND.....	73	PRIMARY HOUSING.....	43
LAMPS & SPEAKER HOUSINGS - ULTRA TOUR-PAK.....	85	PUSH ROD COVER.....	11
LICENSE PLATE HOLDER.....	77	PUSH RODS.....	11
LOCK - SADDLEBAG.....	211	RADIO.....	197
LOCKSET - COMPLETE.....	209	RADIO CONTROL - PASSENGER.....	85
LOCK - TOUR-PAK.....	83	REAR BRAKE CALIPER.....	63
MAIN WIRING HARNESS - ABS BRAKES (FAIRING MODELS) (1 OF 5).....	167	REAR BRAKE CONTROL.....	59
MAIN WIRING HARNESS - ABS BRAKES (FAIRING MODELS) (2 OF 5).....	169	REAR BRAKE LINES & MODULE - ABS.....	61
MAIN WIRING HARNESS - ABS BRAKES (FAIRING MODELS) (3 OF 5).....	171	REAR FENDER (1 OF 2).....	115
MAIN WIRING HARNESS - ABS BRAKES (FAIRING MODELS) (4 OF 5).....	173	REAR FENDER (2 OF 2).....	117
MAIN WIRING HARNESS - ABS BRAKES (FAIRING MODELS) (5 OF 5).....	175	REAR FORK.....	73
MAIN WIRING HARNESS - ABS BRAKES (NON-FAIRING MODELS) (1 OF 5).....	187	REAR SHOCK ABSORBERS & AIR SUSPENSION SYSTEM.....	87
MAIN WIRING HARNESS - ABS BRAKES (NON-FAIRING MODELS) (2 OF 5).....	189	REAR WHEEL.....	65
MAIN WIRING HARNESS - ABS BRAKES (NON-FAIRING MODELS) (3 OF 5).....	191	RELAY, STARTER.....	31
MAIN WIRING HARNESS - ABS BRAKES (NON-FAIRING MODELS) (4 OF 5).....	193	RELAY WITH DIODE.....	157
MAIN WIRING HARNESS - ABS BRAKES (NON-FAIRING MODELS) (5 OF 5).....	195	RELAY WITH DIODE.....	167
MAIN WIRING HARNESS - NON-ABS BRAKES (FAIRING MODELS) (1 OF 5).....	157	RELAY WITH DIODE.....	177
MAIN WIRING HARNESS - NON-ABS BRAKES (FAIRING MODELS) (2 OF 5).....	159	RELAY WITH DIODE.....	187
MAIN WIRING HARNESS - NON-ABS BRAKES (FAIRING MODELS) (3 OF 5).....	161	REMOTE CONTROL - FOB.....	209
MAIN WIRING HARNESS - NON-ABS BRAKES (FAIRING MODELS) (4 OF 5).....	163	ROCKER ARM ASSEMBLY & PUSH RODS - TWIN CAM 96™.....	11
MAIN WIRING HARNESS - NON-ABS BRAKES (FAIRING MODELS) (5 OF 5).....	165	ROCKER COVER.....	11
MAIN WIRING HARNESS - NON-ABS BRAKES (NON-FAIRING MODELS) (1 OF 5).....	177	ROTOR.....	25
MAIN WIRING HARNESS - NON-ABS BRAKES (NON-FAIRING MODELS) (2 OF 5).....	179	SADDLEBAG GUARDS.....	217
MAIN WIRING HARNESS - NON-ABS BRAKES (NON-FAIRING MODELS) (3 OF 5).....	181	SADDLEBAGS (1 OF 2).....	211
MAIN WIRING HARNESS - NON-ABS BRAKES (NON-FAIRING MODELS) (4 OF 5).....	183	SADDLEBAGS (2 OF 2).....	213
MAIN WIRING HARNESS - NON-ABS BRAKES (NON-FAIRING MODELS) (5 OF 5).....	185	SADDLEBAGS - FLHRC.....	215
MASTER CYLINDER FRONT.....	49	SEATS & REAR FRAME RAILS.....	77
		SECURITY SYSTEM AND TURN SIGNAL CANCELLER.....	209
		SENSOR - AIR TEMP - FLHT, FLHX.....	139
		SENSOR - AIR TEMP - FLTR.....	99
		SENSOR - CRANKSHAFT POSITION.....	29
		SENSOR - TMAP.....	21
		SHIFTER CAM.....	33
		SHIFTER FORK.....	33
		SHOCK - REAR.....	87
		SIDECAR AMPLIFIER HARNESS.....	243
		SIDECAR BODY.....	221
		SIDECAR BRAKE.....	227
		SIDECAR CHASSIS.....	223
		SIDECAR CONNECTION KIT.....	225
		SIDECAR FENDER.....	229
		SIDECAR TAIL LAMP.....	231

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$