

# **ZERO**

**MOTORCYCLES®**



## **2013 - 2024 FX, FXS, FXE SERVICE MANUAL**

**100%**  
ELECTRIC

 **CRAFTED IN  
CALIFORNIA**

8811943-AE

## **EMEA (Europe, Middle East, Africa) Disclaimer**

**This Service Manual has been drawn up by Zero Motorcycles Inc. and is intended for and addressed to technicians authorized by Zero Motorcycles to provide services or to other independent operators that are (in)directly involved and in the repair or maintenance of vehicles, who are in any case properly trained to provide repair and maintenance services and have specialized knowledge of mechanics principles and vehicle fixing techniques and procedures.**

**The Zero motorcycle contains high voltage components that should be treated with extreme caution. Exposure to high voltage can cause shock, burns, and even death. Operating, servicing and maintaining a Zero motorcycle can expose one to chemicals including engine exhaust, carbon monoxide, phthalates, which can lead to reproductive harm. Zero motorcycles should at all times, and only be serviced by specially trained and skilled technicians.**

**This Service Manual is not intended for owners. Zero motorcycles' owners are expressly recommended to consult the relevant Owner's Manual accompanying the motorcycle, which is designed to provide owners with a better understanding of the operation, inspection, and basic maintenance requirements of the motorcycle. Damage, malfunctions, or performance problems caused by the failure to follow recommended repair, service and maintenance requirements stipulated in the Owner's Manual, are not covered by the Zero Motorcycles Limited Warranty.**

**Zero warrants that all original, factory-produced Zero motorcycles are free from defects in material and workmanship, pursuant to the applicable Limited Warranty conditions stipulated in the Owner's Manual accompanying the motorcycle. Zero strongly recommends to have all maintenance and repair services carried out by authorized Zero dealers or service partners. Damage, malfunctions, or performance problems caused to the motorcycle due to or after service or repair by an unauthorized service provider, or due to the improper service, repair or installation of parts/accessories not sold or approved by Zero or altering the motorcycle's specifications from those set by Zero, are not covered by the Zero Motorcycles Limited Warranty.**

## 01 General Information

Description of Safety Cautions, Notices, and Important	1-3
Cautions, Notices and Important	1-3
Unpacking Procedure	1-4
Dealer Pre-Delivery Inspection	1-6
Vehicle Identification	1-8
Tools and Equipment	1-10
General Specifications	1-11
Vibration Diagnostic Process	1-11
Road Testing Procedure	1-12
Warranty Information	1-13
Tire Pressure	1-13
Replacement Bulbs	1-13

## 10 Maintenance and Safety

High Voltage Discharging	10-1
Low Voltage Fuses	10-2
High Voltage Fuses	10-3
Brake Pad/Rotor Inspection	10-4
Drive Belt	10-5
Belt Adjustment - Gates® Carbon Drive™ Smartphone Application	10-6
Belt Adjustment - Tension Tester Tool	10-8
Chain Tension Adjustment	10-9
Diagnostic Trouble Code (DTC) List	10-10

## 20 Power Pack

Powerpack Diagnostics	20-1
Power Pack Replacement (Modular)	20-7
Power Pack Replacement (Integrated)	20-7
BMS Replacement and Configuration (Modular)	20-10
BMS Replacement and Configuration (Integrated)	20-12
Power Pack Harness Replacement (Modular)	20-15
Power Pack Harness Replacement (Integrated)	20-16
BMS Configuration	20-18
Checking and Updating Firmware (MBB and BMS)	20-19
MBB/BMS Interface	20-20

## 25 Charging System

Motor/Charging	25-1
Operation	25-4
DC/DC Converter Replacement (Modular)	25-7
DC/DC Converter Replacement (Integrated)	25-8
Power Pack Charger Replacement	25-10

**30 Motor & Drive System**

Belt Replacement .....	30-1
Chain Replacement .....	30-2
Motor Sprocket Replacement .....	30-3
Rear Drive Sprocket Replacement-Belt .....	30-5
Motor Replacement .....	30-7
Motor Controller Heat Sink Replacement .....	30-9
Motor Controller Replacement .....	30-10
Motor Commissioning .....	30-11
Main Bike Board (MBB) Replacement (Modular) .....	30-13
Main Bike Board (MBB) Replacement (Integrated) .....	30-14
Throttle Replacement .....	30-16

**40 Suspension**

Front Fork Specifications .....	40-1
Rear Suspension Specifications .....	40-2
Description and Operation .....	40-2
Suspension Adjustment .....	40-3
Suspension General Diagnosis .....	40-7
Steering Head Service .....	40-7
Swingarm Assembly Replacement .....	40-13

**45 Brakes**

Hydraulic Brake System Description and Operation .....	45-1
Diagnostics - Non-ABS .....	45-2
Brake Pad Replacement - Front .....	45-3
Brake Pad Replacement - Rear .....	45-5
Brake Bedding .....	45-6
Brake Caliper Replacement - Front .....	45-7
Brake Caliper Replacement - Rear .....	45-8
Brake Rotor Replacement - Front .....	45-10
Brake Rotor Replacement - Rear .....	45-11
Anti-Lock Brake System (ABS) Description and Operation .....	45-14
Disabling the Anti-Lock Brake System (ABS) .....	45-16
ABS Hydraulic Control Unit (HCU) Replacement .....	45-16
ABS Sensor Replacement - Front .....	45-17
ABS Sensor Replacement - Rear .....	45-19
ABS Harness Replacement (except 11kW) .....	45-20
ABS Diagnostics .....	45-21

## 60 Body

Body - FX/FXS .....	60-1
Body - FXE .....	60-1

## 70 Electrical

Instrument Panel Replacement .....	70-1
Ignition Switch/Lock Cylinder Replacement .....	70-2
Right Handlebar Control Replacement .....	70-3
Headlight Adjustment .....	70-5
Headlight Bulb Replacement .....	70-5
Turn Signal Flasher Replacement .....	70-7
Tail Light Replacement .....	70-7
Main Chassis Harness Replacement (11kW) .....	70-9
Main Chassis Harness Replacement (except 11kW) .....	70-12

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$