Service Manual



Wheeled Loading Shovel - 434S/435S

Section 1 - General Information

Section 2 - Care and Safety

Section 3 - Routine Maintenance

Section A - Attachments

Section B - Body and Framework

Section C - Electrics

Section E - Hydraulics

Section F - Transmission

Section G - Brakes

Section H - Hydraulic Steering

Section K - Engine



Publication No. **9803/9420-3**



Guotomor G

World Class

Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

Section 1



General Information

Section 1 - General Information

Section 2 - Care and Safety

Section 3a - Routine Maintenance

Section 3b - Routine Maintenance

Section A - Attachments

Section B - Body and Framework

Section C - Electrics

Section E - Hydraulics

Section F - Transmission

Section G - Brakes

Section H - Hydraulic Steering

Section K - Engine



Publication No. **9803/9420-3**



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

World Class
Customer Suppor



Section 1 - General Information

Notes:	



Section 1 - General Information

Contents	Page No.
Introduction	
About this Publication	1 - 1
Identifying your Machine	
434S	1 - 5
435S	1 - 8
Torque Settings	
Zinc Plated Fasteners and Dacromet Fasten	
Hydraulic Connections	1 - 13
Service Tools	
Numerical List	
Tool Detail Reference	1 - 18
Service Consumables	
Sealing and Retaining Compounds	1 - 37
Terms and Definitions	
Colour Coding	1 - 39



Section 1 - General Information

Contents Page No.

1-ii 1-ii

It's a preview. You can download the full file by clicking the link below.

https://shopservicemanual.com/

Service Manuals from 2\$