

Service Manual



WLS 430ZX

[Section 1 - General Information](#)

[Section 2 - Care and Safety](#)

[Section 3 - Routine Maintenance](#)

[Section B - Body and Framework](#)

[Section C - Electrics](#)

[Section E - Hydraulics](#)

[Section F - Transmission](#)

[Section G - Brakes](#)

[Section H - Steering](#)



Publication No.
9813/1050



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

World Class
Customer Support

Section 1



General Information

Service Manual - Service Manual

[Section 1 - General Information](#)

[Section 2 - Care and Safety](#)

[Section 3 - Routine Maintenance](#)

[Section B - Body and Framework](#)

[Section C - Electrics](#)

[Section E - Hydraulics](#)

[Section F - Transmission](#)

[Section G - Brakes](#)

[Section H - Steering](#)



Publication No.

-



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

World Class
Customer Support



Section 1 - General Information

Notes:



Section 1 - General Information

Contents

Contents	Page No.
Introduction	
About this Manual	1-1
Machine Model and Serial Number	1-1
Using this Manual	1-1
Left Side, Right Side	1-1
Cab/Canopy	1-1
Cross References	1-1
Machine Description	1-2
The JCB Wheeled Loader	1-2
Intended Use	1-2
Component Location	1-2
Identifying Your Machine	1-4
Machine Identification Plate	1-4
Standard Torque Settings	
Zinc Plated Fasteners and Dacromet Fasteners	1-5
Introduction	1-5
Bolts and Screws	1-5
Hydraulic Connections	1-9
'O' Ring Face Seal System	1-9
'Torque Stop' Hose System	1-12
JCB Standard Torque Settings	1-13
B.S.P. Port Connection (Colour Coded)	1-13
Hose Ends and Flanged Fittings (Colour Coded)	1-14
Service Tools	
Numerical List	1-15
Tool Detail Reference Section B - Body and Framework	1-16
Numerical List Section C - Electrics	1-20
Tool Detail Reference Section C - Electrics	1-21
Numerical List Section E - Hydraulics	1-22
Tool Detail Reference Section E - Hydraulics	1-25
Numerical List Section F - Transmission	1-28
Tool Detail Reference Section F - Transmission	1-29
Numerical List Section K - Engine	1-32
Tool Detail Reference Section K - Engine	1-33
Service Consumables	
Sealing and Retaining Compounds	1-35
Terms and Definitions	
Colour Coding	1-37
Hydraulic Schematic Colour Codes	1-37



Section 1 - General Information

Contents

Contents	Page No.
----------	----------

It's a preview. You can download the full file by
clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$