

WSM

WORKSHOP MANUAL
**TRACTOR, MOWER,
FRONT LOADER**

**BX1870, BX2370, BX2670,
RCK48-18BX, RCK54-23BX,
RCK60B-23BX,
RCK48P-18BX, RCK54P-23BX,
RCK54D-26BX, RCK60D-26BX,
LA203A, LA243A**

Kubota

TO THE READER

This Workshop Manual tells the servicing personnel about the mechanism, servicing and maintenance of KUBOTA Tractor BX1870D, BX2370D, BX2670D, KUBOTA Rotary Mower RCK48-18BX, RCK54-23BX, RCK60B-23BX, RCK48P-18BX, RCK54P-23BX, RCK60D-26BX, RCK54D-26BX and KUBOTA Front Loader LA203A, LA243A. It contains 4 parts: **"Information"**, **"General"**, **"Mechanism"** and **"Servicing"**.

■ Information

This section primarily contains information below.

- Safety First
- Safety Decal
- Specifications
- Dimensions

■ General

This section primarily contains information below.

- Engine Identification
- Model Identification
- General Precautions
- Maintenance Check List
- Check and Maintenance
- Special Tools

■ Mechanism

This section contains information on the structure and the function of the unit. Before you continue with the subsequent sections, make sure that you read this section.

Refer to the latest version of Workshop Manual (Code No. 9Y021-01870 / 9Y021-18200) for the diesel engine / tractor mechanism that this workshop manual does not include.

■ Servicing

This section primarily contains information below.

- Troubleshooting
- Servicing Specifications
- Tightening Torques
- Checking, Disassembling and Servicing

All illustrations, photographs and specifications contained in this manual are of the newest information available at the time of publication.

KUBOTA reserves the right to change all information at any time without notice.

Since this manual includes many models, information or illustrations and photographs can show more than one model.

December, 2012

© KUBOTA Corporation 2012

Record of Revisions

For pdf, use search function {Search word} to find all the revised locations.

Last digit of the Code No.	Issue month	Main Revised Point and Corrective Measures {Search word}	Reference Page
1	2013.08	Change to the Quick Hitch type at "[2] FRONT LOADER (1) Bucket, Boom and Hydraulic Cylinders". {Bucket (Quick Hitch)}	8-S6
2	2015.05	Added RCK54D-26BX and RCK60D-26BX Drive Over Mower Decks.	
3	2016.03	Revise Maintenance Intervals	G-17
4	2017.02	Changed Checking Hydraulic Pump Oil Flow	5-S6

I INFORMATION

INFORMATION

CONTENTS

1. SAFETY FIRST	I-1
2. SAFETY DECALS	I-4
[1] BX TRACTOR	I-4
[2] MOWER	I-8
[3] FRONT LOADER	I-12
3. SPECIFICATIONS	I-14
[1] BX TRACTOR	I-14
[2] MOWER	I-15
(1) RCK48-18BX, RCK54-23BX, RCK60B-23BX, RCK48P-18BX and RCK54P-23BX	I-15
(2) RCK54D-26BX and RCK60D-26BX	I-16
[3] FRONT LOADER	I-17
4. TRAVELING SPEEDS	I-20
5. DIMENSIONS	I-21

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$