WORKSHOP MANUAL TRACTOR

M108S Low Profile

Kubota

TO THE READER

This Workshop Manual tells the servicing personnel about the mechanism, servicing and maintenance of the M108S-LP. It contains 4 parts: "Information", "General", "Mechanism" and "Servicing".

■ Information

This section primarily contains information below.

- · Safety First
- · Safety Decal
- Specification
- Dimension

■ General

This section primarily contains information below.

- Engine Identification
- Model Identification
- · General Precautions
- · Maintenance Check List
- · Check and Maintenance
- Special Tools

■ Mechanism

This section contains information on the structure and the function of the unit. Before you continue with the subsequent sections, make sure that you read this section.

Refer to the latest version of Workshop Manual for diesel engine / tractor mechanism that this manual does not include.

- Booklet: Code No. 9Y021-01870 / 9Y021-18200
- PDF file in Kubota Web Site: Code No. 9Y011-01870 / 9Y011-18200

■ Servicing

This section primarily contains information below.

- Troubleshooting
- Servicing Specifications
- · Tightening Torques
- · Checking, Disassembling and Servicing

All illustrations, photographs and specifications contained in this manual are of the newest information available at the time of publication.

KUBOTA reserves the right to change all information at any time without notice.


August 2016

© KUBOTA Corporation 2016

Record of Revisions

For pdf, use search function {Search word} to find all the revised locations.

Last digit of the Code No.	Month of Revision	Main Revised Point and Corrective Measures {Search word}	Reference Page
1	2018.02	Update of brake master cylinder service content.	G-39, 5-S7, 5-S11
2	2018.03	Additional information Additional information regarding the assembly procedure of the new type spiral bevel pinion shaft	3-S37, 3-S56
		Wrong correction Disassembly procedure in parking brake case was corrected.	5-S3, 5-S17
3	2020.09	Added the return spring to hydraulic shuttle valve.	3-M5



INFORMATION

CONTENTS

1.	SAFETY FIRST	I-1
	SAFETY DECALS	
3.	SPECIFICATIONS	. I-10
4.	TRAVELING SPEEDS	. I-11
	DIMENSIONS	

It's a preview. You can download the full file by clicking the link below.

https://shopservicemanual.com/

Service Manuals from 2\$