

WSM

WORKSHOP MANUAL
UTILITY VEHICLE

RTV400Ci

Kubota

TO THE READER

This Workshop Manual tells the servicing personnel about the mechanism, servicing and maintenance of the RTV400Ci. It contains 4 parts: "**Information**", "**General**", "**Mechanism**" and "**Servicing**".

■ **Information**

This section primarily contains information below.

- Safety First
- Safety Decal
- Specification
- Dimension

■ **General**

This section primarily contains information below.

- Engine Identification
- Model Identification
- General Precautions
- Maintenance Check List
- Check and Maintenance
- Special Tools

■ **Mechanism**

This section contains information on the structure and the function of the unit. Before you continue with the subsequent sections, make sure that you read this section.

Refer to the latest version of Workshop Manual (Code No. 9Y021-01870 / 9Y021-18200) for the diesel engine / tractor mechanism that this workshop manual does not include.

■ **Servicing**

This section primarily contains information below.

- Troubleshooting
- Servicing Specifications
- Tightening Torques
- Checking, Disassembling and Servicing

All illustrations, photographs and specifications contained in this manual are of the newest information available at the time of publication.

KUBOTA reserves the right to change all information at any time without notice.

© KUBOTA Corporation 2012

February 2012

Record of Revisions

For pdf, use search function {Search word} to find all the revised locations.

Last digit of the Code No.	Month of Revision	Main Revised Point and Corrective Measures {Search word}	Reference Page
2	2013.05	Add the safety decals for Europe model. {Europe}	I-9
3	2014.04	Change the shape of the power train support.	G-49
4	2016.01	Revised Maintenance Intervals.	G-13
5	2017.03	Revised Harness voltage of injector	7-S18
6	2017.12	Corrected the expression of lubricants.	G-9, G-18, G-40, G-43, 3-S13, 4-S6, 4-S7, 4-S8, 4-S18
		Corrected the "Changeing Engine Oil", "Checking Engine Start System", and "Checking Battery Condition" of Maintenance Intervals.	G-21, G-26, G-31

I INFORMATION

INFORMATION

CONTENTS

1. SAFETY FIRST	I-1
2. SAFETY DECALS	I-4
[1] North America and Oceania	I-4
[2] Europe	I-9
3. SPECIFICATIONS.....	I-14
4. TRAVELLING SPEEDS.....	I-15
5. DIMENSIONS	I-16

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$