




Bobcat®

Cutter Crusher

Model 30
Model 40

Service Manual

Model 30 – S/N 991100101 & Above
Model 40 – S/N 991300101 & Above



Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Bobcat Company or the products of either.



MAINTENANCE SAFETY




WARNING









Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903



Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.



-  Never service attachments without instructions. See Operation & Maintenance Manual and Attachment Service Manual.
-  Cleaning and maintenance are required daily.
-  Never service or adjust attachment with the engine running unless instructed to do so in manual.
-  Always lower the attachment to the ground before lubricating or servicing.
-  Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate skin or eyes.
-  Stop, cool and clean engine of flammable materials before checking fluids.
-  Keep body, loose objects and clothing away from moving parts, electrical contacts, hot parts and exhaust.
-  Safety glasses are needed for eye protection from electrical arcs, battery acid, compressed springs, fluids under pressure and flying debris or when tools are used. Use eye protection approved for type of welding.



Bobcat®

ALPHABETICAL INDEX

CRUSHER TEETH REPLACEMENT	10-01
CUTTER CRUSHER (MODEL 30)	30-01
CUTTER CRUSHER (MODEL 40)	30-01
CUTTING BLADES	10-01
GLOSSARY OF HYDRAULIC SYMBOLS	40-01
HARD-SURFACING WEAR AREAS	10-01
HYDRAULIC CYLINDER (MODEL 30)	20-01
HYDRAULIC CYLINDER (MODEL 40)	20-01
HYDRAULIC SCHEMATIC (MODEL 30/40)	40-01
INSPECTION	10-01
LUBRICATION	10-01
PARTS IDENTIFICATION	iv
SERIAL NUMBER LOCATION	iii
SPECIFICATIONS (MODEL 30)	40-01
SPECIFICATIONS (MODEL 40)	40-01
TROUBLESHOOTING	10-01
WELDING TEMPLATE INFORMATION	10-01

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$