

SERVICE MANUAL

TD65F / TD75F / TD85F
Tractor

Part number 48064954

English
September 2016





SERVICE MANUAL

**TD65F
TD75F
TD85F**

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
Clutch	18
[18.110] Clutch and components	18.1
Transmission.....	21
[21.114] Mechanical transmission	21.1
[21.160] Creeper	21.2
[21.162] Reverser	21.3
[21.182] Differential.....	21.4
Four-Wheel Drive (4WD) system	23
[23.202] Electro-hydraulic control	23.1
[23.304] Four-Wheel Drive (4WD) gearbox	23.2
Front axle system	25
[25.100] Powered front axle	25.1
[25.102] Front bevel gear set and differential	25.2
[25.108] Final drive hub, steering knuckles, and shafts	25.3
[25.310] Final drives	25.4
Rear axle system.....	27
[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential	27.2
Power Take-Off (PTO).....	31
[31.101] Rear mechanical control	31.1
Brakes and controls	33
[33.220] Trailer brake hydraulic control.....	33.1
[33.202] Hydraulic service brakes	33.2

Hydraulic systems.....	35
[35.204] Remote control valves	35.1
[35.114] Three-point hitch control valve	35.2
[35.322] Regulated/Low pressure system	35.3
Hitches, drawbars, and implement couplings.....	37
[37.110] Rear three-point hitch	37.1
Steering.....	41
[41.206] Pump	41.1
[41.216] Cylinders	41.2
[41.200] Hydraulic control components.....	41.3
Electrical systems	55
[55.301] Alternator.....	55.1
[55.201] Engine starting system	55.2
[55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls.....	55.3
[55.523] Cab hitch controls	55.4
[55.408] Warning indicators, alarms, and instruments	55.5
[55.302] Battery.....	55.6
[55.100] Harnesses and connectors.....	55.7
Platform, cab, bodywork, and decals	90
[90.154] Cab doors and hatches	90.1
[90.151] Cab interior.....	90.2

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$