

Technical Manual

Operational Principle

ZW

220-6

Wheel Loader

 **Hitachi Construction Machinery Co., Ltd.**

URL:<http://www.hitachi-c-m.com>

SECTION 1

GENERAL

CONTENTS

Group 1 Specifications

Specifications T1-1-1

Group 2 Component Layout

Main Component (Overview) T1-2-1
Main Component..... T1-2-3
Electrical System (Overview) T1-2-5
Air Cleaner and Radiator Assembly..... T1-2-6
Battery Box..... T1-2-8
Hydraulic Oil Tank T1-2-9
Fuel Tank T1-2-10
Drive Unit..... T1-2-11
Front Axle..... T1-2-12
Cab T1-2-13
Engine T1-2-19
Aftertreatment Device T1-2-20
Fan Valve T1-2-21
Pump Device T1-2-22
Control Valve..... T1-2-22
Manifold Valve..... T1-2-23
Parking Brake Solenoid Valve T1-2-23
Brake Charge Valve..... T1-2-23
2-Spool Solenoid Valve Unit..... T1-2-23
Emergency Steering Block..... T1-2-24
Emergency Steering Pump T1-2-24
Flow Regulator Valve T1-2-24
DEF Tank..... T1-2-25
DEF Supply Module..... T1-2-25

Group 3 Component Specifications

Engine T1-3-1
Engine Accessories T1-3-5
Hydraulic Component..... T1-3-6
Electrical Component..... T1-3-12

(Blank)

SECTION 2

SYSTEM

CONTENTS

Group 1 Controller

Outline	T2-1-1
CAN Circuit	T2-1-2

Group 2 Control System

Outline	T2-2-1
Engine Control (ECM)	T2-2-4
Pump Control	T2-2-37
Transmission Control (TCU)	T2-2-42
Forward/Reverse Lever Priority Control (Option) ..	T2-2-46
Fan Control, Valve Control	T2-2-61
Control by Electrical and Hydraulic Combined Circuit	T2-2-93

Group 3 Engine System

Outline	T2-3-1
ECM System	T2-3-2
Fuel Injection Control	T2-3-4
Fuel Injection Amount Correction Control	T2-3-12
EGR Control	T2-3-14
Preheating Control	T2-3-16
Variable Turbocharger Control	T2-3-17
Alarm Control	T2-3-18
Urea SCR System	T2-3-19
Engine Output Restriction Control (INDUCEMENT)	T2-3-30
Aftertreatment Device	T2-3-36
Aftertreatment Device Regeneration Control	T2-3-38

Group 4 Hydraulic System

Outline	T2-4-1
Pilot Circuit	T2-4-2
Parallel Circuit Flow Rate Control	T2-4-32
Main Circuit	T2-4-34
Fan Circuit	T2-4-48
Emergency Steering Circuit (Option)	T2-4-50

Group 5 Electrical System

Outline	T2-5-1
Main Circuit	T2-5-2
Electric Power Circuit (Key Switch: OFF)	T2-5-4
CAN Circuit	T2-5-6
Accessory Circuit (Key Switch: ACC)	T2-5-8
Starting Circuit (Key Switch: START)	T2-5-10
Charging Circuit (Key Switch: ON)	T2-5-12
Surge Voltage Prevention Circuit	T2-5-16
Pilot Shut-Off Circuit (Key Switch: ON)	T2-5-18

Auto Shut-Down Circuit (Option)	T2-5-20
Engine Stop Circuit	T2-5-22
Air Conditioner Circuit	T2-5-24
Steering Column Box Circuit	T2-5-27
Headlight Circuit	T2-5-28
Hazard Light Circuit (Key Switch: OFF)	T2-5-34
Turn Signal Light Circuit	T2-5-36
Horn Circuit (Key Switch: OFF)	T2-5-38
Back Buzzer Circuit	T2-5-40
Brake Light Circuit	T2-5-42
Parking Brake Circuit	T2-5-44
Accessory Circuit	T2-5-49
Work Light Circuit	T2-5-50
Wiper Circuit	T2-5-52
Cab Light Circuit	T2-5-58

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$