

**MINOTAUR DL550**  
**Tier 4B (Final)**  
Compact Dozer Loader

**SERVICE MANUAL**



**Part number 92130848**

English  
May 2024





# **SERVICE MANUAL**

**DL550**

## Link Product / Engine

---

| Product                                       | Market Product | Engine         |
|-----------------------------------------------|----------------|----------------|
| DL550 Tier 4B (final) [NPM440000 - ]          | North America  | F5BFL413D*C002 |
| DL550 Tier 4B (final) [NMM400002 - NPM439999] | North America  | F5BFL413D*C002 |

# Contents

---

## INTRODUCTION

|                                                                     |       |
|---------------------------------------------------------------------|-------|
| Engine.....                                                         | 10    |
| [10.001] Engine and crankcase .....                                 | 10.1  |
| [10.103] Crankshaft and flywheel.....                               | 10.2  |
| [10.206] Fuel filters .....                                         | 10.3  |
| [10.202] Air cleaners and lines .....                               | 10.4  |
| [10.254] Intake and exhaust manifolds and muffler .....             | 10.5  |
| [10.500] Selective Catalytic Reduction (SCR) exhaust treatment..... | 10.6  |
| [10.400] Engine cooling system .....                                | 10.7  |
| [10.414] Fan and drive .....                                        | 10.8  |
| [10.310] Aftercooler.....                                           | 10.9  |
| [10.304] Engine lubrication system.....                             | 10.10 |
| Power coupling.....                                                 | 19    |
| [19.121] Pump-drive assembly .....                                  | 19.1  |
| Hydrostatic drive.....                                              | 29    |
| [29.218] Pump and motor components.....                             | 29.1  |
| [29.202] Hydrostatic transmission .....                             | 29.2  |
| Hydraulic systems.....                                              | 35    |
| [35.000] Hydraulic systems.....                                     | 35.1  |
| [35.300] Reservoir, cooler, and filters.....                        | 35.2  |
| [35.106] Variable displacement pump .....                           | 35.3  |
| [35.105] Charge pump.....                                           | 35.4  |
| [35.359] Main control valve.....                                    | 35.5  |
| [35.741] Dozer blade cylinders .....                                | 35.6  |
| [35.742] Ripper hydraulic system.....                               | 35.7  |
| Tracks and track suspension.....                                    | 48    |

|                                                                                 |           |
|---------------------------------------------------------------------------------|-----------|
| [48.130] Track frame and driving wheels .....                                   | 48.1      |
| [48.100] Tracks .....                                                           | 48.2      |
| [48.134] Track tension units .....                                              | 48.3      |
| [48.138] Track rollers .....                                                    | 48.4      |
| <b>Cab climate control .....</b>                                                | <b>50</b> |
| [50.100] Heating .....                                                          | 50.1      |
| [50.104] Ventilation .....                                                      | 50.2      |
| [50.200] Air conditioning .....                                                 | 50.3      |
| <b>Electrical systems .....</b>                                                 | <b>55</b> |
| [55.000] Electrical system .....                                                | 55.1      |
| [55.100] Harnesses and connectors .....                                         | 55.2      |
| [55.525] Cab engine controls .....                                              | 55.3      |
| [55.015] Engine control system .....                                            | 55.4      |
| [55.201] Engine starting system .....                                           | 55.5      |
| [55.302] Battery .....                                                          | 55.6      |
| [55.011] Fuel tank system .....                                                 | 55.7      |
| [55.988] Selective Catalytic Reduction (SCR) electrical system .....            | 55.8      |
| [55.012] Engine cooling system .....                                            | 55.9      |
| [55.013] Engine oil system .....                                                | 55.10     |
| [55.640] Electronic modules .....                                               | 55.11     |
| [55.019] Hydrostatic drive control system .....                                 | 55.12     |
| [55.512] Cab controls .....                                                     | 55.13     |
| [55.036] Hydraulic system control .....                                         | 55.14     |
| [55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system ..... | 55.15     |
| [55.530] Camera .....                                                           | 55.16     |
| [55.518] Wiper and washer system .....                                          | 55.17     |
| [55.642] Vehicle display .....                                                  | 55.18     |
| [55.509] Operator seat .....                                                    | 55.19     |

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$