

Shop Manual

HYDRAULIC
EXCAVATOR

PC27MR-3

PC30MR-3

PC35MR-3

SERIAL NUMBERS

PC27MR-20002

PC30MR-30001

PC35MR-15001

and up

KOMATSU

HYDRAULIC EXCAVATOR

PC27MR-3

PC30MR-3

PC35MR-3

Machine model	Serial number
---------------	---------------

PC27MR-3	20002 and up
PC30MR-3	30001 and up
PC35MR-3	15001 and up

00 Index and foreword

100 Index

Composition of shop manual	2
Table of contents	4

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly.

The marks shown to the right of Form No. denote the following:

○: New issue (to be filed additionally) ●: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:

- Place a divider on the top of each section in the file after matching the Tub No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

Section Title	Form Number
Shop Manual, contents binder, binder label and tabs	SEN04063-07
00 Index and foreword	SEN04064-07
100 Index	SEN04065-07 ●
200 Foreword and general information	SEN04066-02
01 Specification	SEN04067-02
100 Specification and technical data.....	SEN04068-02
10 Structure, function and maintenance standard.....	SEN04069-03
100 Engine and cooling system	SEN04070-00
200 Power train.....	SEN04071-00
300 Undercarriage and frame	SEN04072-00
410 Hydraulic system, Part 1	SEN04073-02
420 Hydraulic system, Part 2	SEN04074-00
430 Hydraulic system, Part 3	SEN04075-02
500 Work equipment.....	SEN04076-00
600 Cab and its attachments	SEN04077-00
700 Electrical system	SEN04078-01
20 Standard value table.....	SEN04079-02
100 Standard service value table	SEN04380-02
30 Testing and adjusting	SEN04080-02
100 Testing and adjusting	SEN04381-02 ●
40 Troubleshooting.....	SEN04081-02
010 Failure code table and failure locations.....	SEN05815-00 ○
100 General information on troubleshooting.....	SEN04382-01
110 Troubleshooting by failure code	SEN05816-00 ○
200 Troubleshooting of electrical system (E-mode).....	SEN04383-01
300 Troubleshooting of hydraulic and mechanical system (H-mode)	SEN04384-00
400 Troubleshooting of engine (S-mode).....	SEN04385-00

50 Disassembly and assembly	SEN04082-01
100 General information on disassembly and assembly.....	SEN04386-00
200 Engine and cooling system	SEN04387-00
300 Power train	SEN04388-00
400 Undercarriage and frame	SEN04389-00
500 Hydraulic system	SEN04390-00
600 Work equipment	SEN04391-00
700 Cab and its attachments.....	SEN04392-00
800 Electrical system	SEN04393-01
90 Diagrams and drawings	SEN04083-03
100 Hydraulic diagrams and drawings	SEN04084-01
200 Electrical diagrams and drawings.....	SEN04085-03

Table of contents

00 Index and foreword

100 Index	SEN04065-07
Composition of shop manual	2
Table of contents	4
200 Foreword and general information	SEN04066-02
Safety notice	2
How to read the shop manual	7
Explanation of terms for maintenance standard	9
Handling of electric equipment and hydraulic component	11
Handling of connectors newly used for engines	20
How to read electric wire code	23
Precautions when carrying out operation	26
Method of disassembling and connecting push-pull type coupler	29
Standard tightening torque table	32
Conversion table	36

01 Specification

100 Specification and technical data	SEN04068-02
Specification dimension drawing	2
Working range drawing	3
Specifications	4
Weight table	14
Table of fuel, coolant and lubricants	19

10 Structure, function and maintenance standard

100 Engine and cooling system	SEN04070-00
PTO	2
Cooling system	4
200 Power train	SEN04071-00
Power train	2
Swing circle	4
Swing machinery	5
300 Undercarriage and frame	SEN04072-00
Track frame	2
Idler cushion	3
Idler	4
Track roller	6
Carrier roller	7
Sprocket	8
Track shoe	9
410 Hydraulic system, Part 1	SEN04073-02
Hydraulic components layout drawing	2
Hydraulic tank, filter	3
Center swivel joint	5
Travel motor	7
Hydraulic cylinder	15
Solenoid valve	20
Multi-control valve	26
420 Hydraulic system, Part 2	SEN04074-00
Hydraulic pump	2
Control valve	18

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$