

Shop Manual

HYDRAULIC
EXCAVATOR

PC45MR-3
PC55MR-3

SERIAL NUMBERS

PC45MR- 5001
PC55MR-15001

and up

KOMATSU

HYDRAULIC EXCAVATOR

PC45MR-3

PC55MR-3

Machine model	Serial number
PC45MR-3	5001 and up
PC55MR-3	15001 and up

00 Index and foreword

100 Index

Composition of shop manual	2
Table of contents	4

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly.

The marks shown to the right of Form No. denote the following:

○: New issue (to be filed additionally) ●: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:

- Place a divider on the top of each section in the file after matching the Tub No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

Section Title	Form Number
Shop Manual, contents binder, binder label and tabs	SEN04597-07
00 Index and foreword	SEN04598-07
100 Index	SEN04599-07 ●
200 Foreword and general information	SEN04600-01
01 Specification	SEN04601-00
100 Specification and technical data.....	SEN04602-00
10 Structure, function and maintenance standard.....	SEN04603-04
100 Engine and cooling system	SEN04604-00
200 Power train.....	SEN04605-00
300 Undercarriage and frame	SEN04606-00
410 Hydraulic system, Part 1	SEN04607-03
420 Hydraulic system, Part 2	SEN04608-01
430 Hydraulic system, Part 3	SEN04609-01
500 Work equipment.....	SEN04610-01 ●
600 Cab and its attachments	SEN04611-00
700 Electrical system	SEN04612-02
20 Standrad value table.....	SEN04613-01
100 Standard service value table	SEN04648-01
30 Testing and adjusting	SEN04614-01
100 Testing and adjusting	SEN04649-01
40 Troubleshooting.....	SEN04615-01
110 Failure code table and fuse locations	SEN05473-00
120 General information on troubleshooting.....	SEN04650-01
130 Troubleshooting by faivlure code	SEN05474-00
200 Troubleshooting of electrical system (E-mode).....	SEN04651-00
300 Troubleshooting of hydraulic and mechanical system (H-mode)	SEN04652-00
400 Troubleshooting of engine (S-mode).....	SEN04653-00
50 Disassembly and assembly.....	SEN04616-02
100 General information on disassembly and assembly	SEN04654-01

200	Engine and cooling system	SEN04655-00
300	Power train	SEN04656-01
400	Undercarriage and frame	SEN04657-00
500	Hydraulic system	SEN04658-00
600	Work equipment	SEN04659-01 ●
700	Cab and its attachments	SEN04660-00
800	Electrical system	SEN04661-01
90	Diagrams and drawings	SEN04617-04
100	Hydraulic diagrams and drawings	SEN04618-01
200	Electrical diagrams and drawings	SEN04619-04 ●

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$