

Technical Manual

Operational Principle

ZH

200-5A

200LC-5A

Hydraulic Excavator

 **Hitachi Construction Machinery Co., Ltd.**
URL:<http://www.hitachi-c-m.com>

Service Manual consists of the following separate Part No.
Technical Manual (Operational Principle) : Vol. No.TODFM90-EN
Technical Manual (Troubleshooting) : Vol. No.TTDFM90-EN
Workshop Manual : Vol. No.WDFM90-EN
Engine Manual : Vol. No.ETDCY-EN, EWDCY-EN

SECTION AND GROUP CONTENTS

TECHNICAL MANUAL

(Operational Principle)

SECTION 1 GENERAL

Group 1 Specification	
-----------------------	--

Group 2 Component Layout	
--------------------------	--

Group 3 Component Specifications	
----------------------------------	--

SECTION 2 SYSTEM

Group 1 Controller	
--------------------	--

Group 2 Control System	
------------------------	--

Group 3 ECM System	
--------------------	--

Group 4 Hydraulic System	
--------------------------	--

Group 5 Electrical System	
---------------------------	--

SECTION 3 COMPONENT OPERATION

Group 1 Pump Device	
---------------------	--

Group 2 Swing Device	
----------------------	--

Group 3 Control Valve	
-----------------------	--

Group 4 Pilot Valve	
---------------------	--

Group 5 Travel Device	
-----------------------	--

Group 6 Signal Control Valve	
------------------------------	--

Group 7 Others (Upperstructure)	
---------------------------------	--

Group 8 Others (Undercarriage)	
--------------------------------	--

SECTION 6 HYBRID SYSTEM

Group 1 General	
-----------------	--

Group 2 Component Layout	
--------------------------	--

Group 3 Components Specifications	
-----------------------------------	--

Group 4 Control of Hybrid System	
----------------------------------	--

Group 5 Component Operation	
-----------------------------	--

All information, illustrations and specifications in this manual are based on the latest product information available at the time of publication. The right is reserved to make changes at any time without notice.

TECHNICAL MANUAL (Troubleshooting)	WORKSHOP MANUAL
SECTION 4 OPERATIONAL PERFORMANCE TEST - Group 1 Introduction - Group 2 Standard - Group 3 Engine Test - Group 4 Excavator Test - Group 5 Component Test SECTION 5 TROUBLESHOOTING - Group 1 Diagnosing Procedure - Group 2 Monitor - Group 3 e-Service - Group 4 Component Layout - Group 5 Troubleshooting A - Group 6 Troubleshooting B - Group 7 Air Conditioner SECTION 7 HYBRID TROUBLESHOOTING - Group 1 Standard - Group 2 Diagnosing Procedure of Troubleshooting - Group 3 Monitor - Group 4 Component Layout - Group 5 Troubleshooting A - Group 6 Troubleshooting B	SECTION 1 GENERAL INFORMATION - Group 1 Precautions for Disassembling and Assembling - Group 2 Tightening Torque - Group 3 Painting - Group 4 Bleeding Air from Hydraulic Oil Tank - Group 5 Hydraulic Circuit Pressure Release Procedure - Group 6 Preparation SECTION 2 MAINTENANCE STANDARD - Group 1 Upperstructure - Group 2 Undercarriage - Group 3 Attachment SECTION 3 UPPERSTRUCTURE - Group 1 Cab - Group 2 Counterweight - Group 3 Main Frame - Group 4 Engine - Group 5 Radiator - Group 6 Hydraulic Oil Tank - Group 7 Fuel Tank - Group 8 Pump Device - Group 9 Control Valve - Group 10 Swing Device - Group 11 Pilot Valve - Group 12 Solenoid Valve - Group 13 Signal Control Valve SECTION 4 UNDERCARRIAGE - Group 1 Swing Bearing - Group 2 Travel Device - Group 3 Center Joint - Group 4 Track Adjuster - Group 5 Upper and Lower Roller - Group 6 Track SECTION 5 ATTACHMENT - Group 1 Front Attachment - Group 2 Cylinder - Group 3 Hose Rupture Valve

SECTION 1

GENERAL

CONTENTS

Group 1 Specifications

Specifications	T1-1-1
Working Ranges (Grouser shoe)	T1-1-2

Group 2 Component Layout

Main Component	T1-2-1
Electrical System (Overview)	T1-2-2
Electrical System (Rear Tray)	T1-2-3
Electrical System (Switch Panel)	T1-2-4
Electrical System (Around Air Cleaner)	T1-2-5
Electrical System (Relay, Sensor)	T1-2-6
Electrical System (Battery)	T1-2-7
Engine	T1-2-8
Pump Device	T1-2-9
Around Pump Device	T1-2-10
Control Valve	T1-2-11
Signal Control Valve	T1-2-11
Swing Device	T1-2-13
Travel Device	T1-2-13
5-Spool Solenoid Valve Unit	T1-2-14
Pump 3 Center Bypass Shut-Out Control Solenoid Valve	T1-2-14

Group 3 Component Specifications

Engine	T1-3-1
Engine Accessories	T1-3-5
Hydraulic Component	T1-3-6
Electrical Component	T1-3-10

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$