

CX50D
CX55D

Mini Excavator

SERVICE MANUAL

Part number 92115826

English

February 2024

© 2024 CNH Industrial Italia S.p.A. All Rights Reserved.

CASE
CONSTRUCTION



SERVICE MANUAL

CX50D
CX55D

Link Product / Engine

Product	Market Product	Engine
CX50D	Latin America	404J-E22TA (IR84382U)
CX50D	Asia Pacific	404J-E22TA (IR84382U)
CX50D	North America	404J-E22TA (IR84382U)
CX50D	Middle East Africa	404J-E22TA (IR84382U)
CX50D	Australia New Zealand	404J-E22TA (IR84382U)
CX50D	Europe	404J-E22TA (IR84382U)
CX55D Cab version [SMP1C246EZMD00062 -]	North America	404J-E22TA (IR84382U)
CX55D Cab version [SMP1C246EZMD00062 -]	Europe	404J-E22TA (IR84382U)
CX55D Cab version [SMP1C246EZMD00062 -]	Australia New Zealand	404J-E22TA (IR84382U)
CX55D Cab version [SMP1C246EZMD00062 -]	Middle East Africa	404J-E22TA (IR84382U)
CX55D Cab version [SMP1C246EZMD00062 -]	Latin America	404J-E22TA (IR84382U)
CX55D Cab version [SMP1C246EZMD00062 -]	Asia Pacific	404J-E22TA (IR84382U)

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.216] Fuel tanks	10.2
[10.206] Fuel filters	10.3
[10.202] Air cleaners and lines	10.4
[10.501] Exhaust Gas Recirculation (EGR) exhaust treatment.....	10.5
[10.400] Engine cooling system	10.6
[10.414] Fan and drive	10.7
[10.304] Engine lubrication system.....	10.8
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.106] Variable displacement pump	35.3
[35.359] Main control valve.....	35.4
[35.357] Pilot system	35.5
[35.220] Auxiliary hydraulic pump	35.6
[35.525] Auxiliary hydraulic valves and lines	35.7
[35.355] Hydraulic hand control	35.8
[35.356] Hydraulic foot control.....	35.9
[35.352] Hydraulic swing system	35.10
[35.353] Hydraulic travel system	35.11
[35.354] Hydraulic central joint	35.12
[35.736] Boom hydraulic system	35.13
[35.737] Dipper hydraulic system.....	35.14
[35.738] Excavator and backhoe bucket hydraulic system.....	35.15
[35.734] Tool quick coupler hydraulic system	35.16

[35.739] Swing arm hydraulic system	35.17
[35.730] Positioning arm hydraulic system	35.18
[35.741] Dozer blade cylinders	35.19
Frames and ballasting	39
[39.103] Swing ring assembly	39.1
[39.140] Ballasts and supports	39.2
Tracks and track suspension	48
[48.130] Track frame and driving wheels	48.1
[48.100] Tracks	48.2
[48.134] Track tension units	48.3
[48.138] Track rollers	48.4
Cab climate control	50
[50.104] Ventilation	50.1
[50.200] Air conditioning	50.2
Electrical systems	55
[55.000] Electrical system	55.1
[55.100] Harnesses and connectors	55.2
[55.201] Engine starting system	55.3
[55.302] Battery	55.4
[55.011] Fuel tank system	55.5
[55.512] Cab controls	55.6
[55.404] External lighting	55.7
[55.991] Telematics	55.8
[55.DTC] FAULT CODES	55.9
Booms, dippers, and buckets	84
[84.114] Boom pivoting support	84.1
[84.910] Boom	84.2
[84.912] Dipper arm	84.3

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$