

Farmall® 25A
Tractor

SERVICE MANUAL

Part number 92189884

English
April 2024





SERVICE MANUAL

FARMALL® 25A 25 Hp, without cab

Link Product / Engine

Product	Market Product	Engine
FARMALL® 25A 25 Hp, without cab	North America	S3L2

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.216] Fuel tanks	10.2
[10.206] Fuel filters	10.3
[10.202] Air cleaners and lines	10.4
[10.254] Intake and exhaust manifolds and muffler	10.5
[10.400] Engine cooling system	10.6
[10.414] Fan and drive	10.7
Clutch	18
[18.100] Clutch mechanical release control	18.1
[18.110] Clutch and components	18.2
Power coupling.....	19
[19.110] Flywheel damper	19.1
Transmission.....	21
[21.114] Mechanical transmission	21.1
[21.130] Mechanical transmission external controls.....	21.2
[21.140] Mechanical transmission internal components.....	21.3
[21.110] Master clutch housing	21.4
Four-Wheel Drive (4WD) system	23
[23.314] Drive shaft.....	23.1
[23.101] Mechanical control	23.2
Front axle system	25
[25.100] Powered front axle	25.1
[25.102] Front bevel gear set and differential	25.2
[25.108] Final drive hub, steering knuckles, and shafts	25.3

Rear axle system..... 27

 [27.106] Rear bevel gear set and differential 27.1

 [27.120] Planetary and final drives 27.2

Hydrostatic drive..... 29

 [29.200] Mechanical control 29.1

 [29.100] Transmission and steering hydrostatic control 29.2

 [29.204] Reservoir, cooler, and lines 29.3

 [29.218] Pump and motor components..... 29.4

 [29.202] Hydrostatic transmission 29.5

Power Take-Off (PTO)..... 31

 [31.101] Rear mechanical control 31.1

 [31.104] Rear electro-hydraulic control..... 31.2

 [31.110] One-speed rear Power Take-Off (PTO) 31.3

 [31.120] Central Power Take-Off (PTO) 31.4

Brakes and controls 33

 [33.110] Parking brake or parking lock 33.1

 [33.120] Mechanical service brakes 33.2

Hydraulic systems..... 35

 [35.000] Hydraulic systems..... 35.1

 [35.300] Reservoir, cooler, and filters..... 35.2

 [35.104] Fixed displacement pump 35.3

 [35.350] Safety and main relief valves 35.4

 [35.204] Remote control valves 35.5

 [35.114] Three-point hitch control valve 35.6

 [35.116] Three-point hitch cylinder 35.7

 [35.724] Front loader hydraulic system control..... 35.8

Hitches, drawbars, and implement couplings..... 37

 [37.100] Drawbars and towing hitches 37.1

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$