

WSM

WORKSHOP MANUAL

TRACTOR, MOWER

**BX1880, BX2380, BX2680,
RCK60B-23BX, RCK54-23BX,
RCK48-18BX, RCK60D-26BX,
RCK54D-26BX**

Kubota

TO THE READER

This Workshop Manual tells the servicing personnel about the mechanism, servicing and maintenance of *BX1880*, *BX2380*, *BX2680*, *RCK60B-23BX*, *RCK54-23BX*, *RCK48-18BX*, *RCK60D-26BX* and *RCK54D-26BX*. It contains 4 parts: "Information", "General", "Mechanism", and "Servicing".

Information

This section primarily contains information below.

- Safety first
- Safety decal
- Specifications
- Dimensions

General

This section primarily contains information below.

- Engine identification
- Model identification
- General precautions
- Maintenance check list
- Check and maintenance
- Special tools

Mechanism

This section contains information on the structure and the function of the unit. Before you continue with the subsequent sections, make sure that you read this section.

Servicing

This section primarily contains information below.

- Troubleshooting
- Servicing specifications (Service specifications)
- Tightening torques
- Checking, disassembling and servicing

All illustrations, photographs and specifications contained in this manual are of the newest information available at the time of publication.

Kubota reserves the right to change all information at any time without notice.

Since this manual includes many models, information or illustrations and photographs can show more than one model.

February 2017

© KUBOTA Corporation

RECORD OF REVISIONS

For pdf, use search function [Search word] to find all the revised locations.

Last digit of the code No.	Month of revision	Main revised point and corrective measure [Search word]	Reference page
1	2017 April	Addition of contents for the model BX1880.	—
2	2019 February	Added quick coupler disassembly and assembly.	2-67 7-50
		Revised service intervals: • Transmission fluid • Transmission strainer	2-15

CONTENTS

1. INFORMATION

SAFETY FIRST	1-1
1. Safety first.....	1-1
2. Before you start service	1-2
3. Start safely.....	1-2
4. Operate safely	1-2
5. Avoiding high pressure fluid.....	1-3
6. Avoiding hot exhaust	1-3
7. Cleaning exhaust filter	1-3
8. Prevent a fire	1-4
9. Keep a good airflow in the work area	1-4
10. Discard fluids correctly	1-4
11. Prevent acid burns.....	1-4
12. Preparing for emergencies	1-5
SAFETY LABEL	1-7
1. Safety labels for BX tractor.....	1-7
2. Safety labels for mower	1-12
2.1 Care of danger, warning and caution labels.....	1-14
SPECIFICATIONS	1-15
1. BX tractor specifications	1-15
2. Mower specifications (RCK60B-23BX, RCK54-23BX and RCK48-18BX).....	1-17
3. Mower specifications (RCK60D-26BX and RCK54D-26BX)	1-18
TRAVELING SPEEDS	1-19
DIMENSIONS	1-21

2. GENERAL

IDENTIFICATION.....	2-1
1. Tractor identification	2-1
1.1 Checking serial number and hour meter.....	2-1
1.2 Cylinder number.....	2-2
2. Checking mower identification.....	2-2
GENERAL PRECAUTIONS.....	2-3
HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING	2-5
LUBRICANTS, FUEL AND COOLANT	2-7
1. BX tractor.....	2-7
1.1 Lubricants, fuel, and coolant	2-7
1.1.1 Fuel.....	2-8
1.1.2 Engine oil.....	2-8
1.1.3 Transmission oil	2-8
1.2 Overview of biodiesel fuel (BDF).....	2-9
2. Mower	2-11
2.1 Lubricants.....	2-11
TIGHTENING TORQUES	2-13
1. General use screws, bolts and nuts	2-13
2. Stud bolts.....	2-13
3. Metric screws, bolts and nuts	2-14
4. American standard screws, bolts and nuts with UNC or UNF threads	2-14
5. Plugs.....	2-14
MAINTENANCE CHECK LIST	2-15
1. BX tractor service intervals.....	2-15
2. Mower service intervals	2-17
CHECK AND MAINTENANCE.....	2-19
1. Periodic service	2-19
1.1 Opening bonnet.....	2-19

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$