

**CX300E**  
Crawler Excavator

SERVICE MANUAL

**Part number 92081885**

English  
March 2023





## **SERVICE MANUAL**

**CX300E LC NA Market [DAC300K8NNS8N1001 - ]**

# Link Product / Engine

---

| Product                                       | Market Product | Engine         |
|-----------------------------------------------|----------------|----------------|
| CX300E LC NA Market<br>[DAC300K8NNS8N1001 - ] | North America  | F4HGE6138*V007 |

# Contents

---

## INTRODUCTION

|                                                                      |       |
|----------------------------------------------------------------------|-------|
| Engine.....                                                          | 10    |
| [10.001] Engine and crankcase .....                                  | 10.1  |
| [10.216] Fuel tanks .....                                            | 10.2  |
| [10.500] Selective Catalytic Reduction (SCR) exhaust treatment ..... | 10.3  |
| [10.400] Engine cooling system .....                                 | 10.4  |
| [10.310] Aftercooler.....                                            | 10.5  |
| Hydraulic systems.....                                               | 35    |
| [35.000] Hydraulic systems.....                                      | 35.1  |
| [35.300] Reservoir, cooler, and filters.....                         | 35.2  |
| [35.106] Variable displacement pump .....                            | 35.3  |
| [35.102] Pump control valves.....                                    | 35.4  |
| [35.359] Main control valve .....                                    | 35.5  |
| [35.357] Pilot system .....                                          | 35.6  |
| [35.820] Hydraulic driven cooling fans .....                         | 35.7  |
| [35.355] Hydraulic hand control .....                                | 35.8  |
| [35.356] Hydraulic foot control.....                                 | 35.9  |
| [35.352] Hydraulic swing system .....                                | 35.10 |
| [35.353] Hydraulic travel system .....                               | 35.11 |
| [35.354] Hydraulic central joint .....                               | 35.12 |
| [35.736] Boom hydraulic system .....                                 | 35.13 |
| [35.737] Dipper hydraulic system.....                                | 35.14 |
| [35.738] Excavator and backhoe bucket hydraulic system.....          | 35.15 |
| [35.734] Tool quick coupler hydraulic system .....                   | 35.16 |
| [35.360] Hammer and rotating bucket hydraulic system .....           | 35.17 |
| Frames and ballasting .....                                          | 39    |

|                                                                                 |           |
|---------------------------------------------------------------------------------|-----------|
| [39.140] Ballasts and supports .....                                            | 39.1      |
| <b>Tracks and track suspension .....</b>                                        | <b>48</b> |
| [48.130] Track frame and driving wheels .....                                   | 48.1      |
| [48.100] Tracks .....                                                           | 48.2      |
| [48.134] Track tension units .....                                              | 48.3      |
| [48.138] Track rollers .....                                                    | 48.4      |
| <b>Cab climate control .....</b>                                                | <b>50</b> |
| [50.200] Air conditioning .....                                                 | 50.1      |
| <b>Electrical systems .....</b>                                                 | <b>55</b> |
| [55.000] Electrical system .....                                                | 55.1      |
| [55.100] Harnesses and connectors .....                                         | 55.2      |
| [55.525] Cab engine controls .....                                              | 55.3      |
| [55.201] Engine starting system .....                                           | 55.4      |
| [55.301] Alternator .....                                                       | 55.5      |
| [55.302] Battery .....                                                          | 55.6      |
| [55.202] Cold start aid .....                                                   | 55.7      |
| [55.011] Fuel tank system .....                                                 | 55.8      |
| [55.010] Fuel injection system .....                                            | 55.9      |
| [55.014] Engine intake and exhaust system .....                                 | 55.10     |
| [55.988] Selective Catalytic Reduction (SCR) electrical system .....            | 55.11     |
| [55.012] Engine cooling system .....                                            | 55.12     |
| [55.640] Electronic modules .....                                               | 55.13     |
| [55.512] Cab controls .....                                                     | 55.14     |
| [55.036] Hydraulic system control .....                                         | 55.15     |
| [55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls .....   | 55.16     |
| [55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system ..... | 55.17     |
| [55.524] Cab controls (Lift arm, Boom, Dipper, Bucket) .....                    | 55.18     |
| [55.416] Swing control system .....                                             | 55.19     |

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$