

SHOP MANUAL



PC95R-2

HYDRAULIC EXCAVATOR

SERIAL NUMBER

PC95R-2 21D5200330 and up



CONTENTS

10 STRUCTURE AND FUNCTION	10-1
20 TESTING AND ADJUSTING.....	20-1
30 REMOVAL AND INSTALLATION	30-1
40 MAINTENANCE STANDARD	40-1

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to table below.

Mark	Indication	Action required
○	Page to be newly	Add
●	Page to be replaced	Replace
()	Page to be delete	Discard

Pages having no marks are those previously revised or made additions.

LIST OF REVISED PAGES

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
	00-1			10-25			10-66			10-107			20-37	
	00-2			10-26			10-67			10-108			20-38	
	00-2-1			10-27			10-68			10-109			20-39	
	00-2-2			10-28			10-69			10-110			20-40	
	00-3			10-29			10-70						20-41	
	00-4			10-30			10-71			20-1			20-42	
	00-5			10-31			10-72			20-2			20-43	
	00-6			10-32			10-73			20-3			20-44	
	00-7			10-33			10-74			20-4			20-45	
	00-8			10-34			10-75			20-5			20-46	
	00-9			10-35			10-76			20-6			20-47	
	00-10			10-36			10-77			20-7			20-48	
	00-11			10-37			10-78			20-8			20-49	
	00-12			10-38			10-79			20-9			20-50	
	00-13			10-39			10-80			20-10			20-51	
	00-14			10-40			10-81			20-11			20-52	
				10-41			10-82			20-12			20-53	
	10-1			10-42			10-83			20-13			20-54	
	10-2			10-43			10-84			20-14			20-55	
	10-3			10-44			10-85			20-15			20-56	
	10-4			10-45			10-86			20-16			20-57	
	10-5			10-46			10-87			20-17			20-58	
	10-6			10-47			10-88			20-18				
	10-7			10-48			10-89			20-19			30-1	
	10-8			10-49			10-90			20-20			30-2	
	10-9			10-50			10-91			20-21			30-3	
	10-10			10-51			10-92			20-22			30-4	
	10-11			10-52			10-93			20-23			30-5	
	10-12			10-53			10-94			20-24			30-6	
	10-13			10-54			10-95			20-25			30-7	
	10-14			10-55			10-96			20-26			30-8	
	10-15			10-56			10-97			20-27			30-9	
	10-16			10-57			10-98			20-28			30-10	
	10-17			10-58			10-99			20-29			30-11	
	10-18			10-59			10-100			20-30			30-12	
	10-19			10-60			10-101			20-31			30-13	
	10-20			10-61			10-102			20-32			30-14	
	10-21			10-62			10-103			20-33			30-15	
	10-22			10-63			10-104			20-34			30-16	
	10-23			10-64			10-105			20-35			30-17	
	10-24			10-65			10-106			20-36			30-18	

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$