

Shop Manual

GALEO

WA450-6

WA480-6

WHEEL LOADER

SERIAL NUMBERS	WA450-6	66001 and up
	WA480-6	85001 and up

This material is proprietary to Komatsu America Corp. and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu America Corp.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

Copyright 2006 Komatsu
Printed in U.S.A.
Komatsu America Corp.

September 2006

WHEEL LOADER

WA450-6 WA480-6 (KA SPEC.)

Machine model	Serial number
---------------	---------------

WA450-6	66001 and up
WA480-6 (KA SPEC.)	85001 and up

00 Index and foreword

Index

Composition of shop manual.....	2
Table of contents	4

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly.

The marks shown to the right of Form No. denote the following:

○: New issue (to be filed additionally) ●: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:

- Place a divider on the top of each section in the file after matching the Tub No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

Section Title	Form Number
Shop Manual, contents binder, binder label and tabs	SEN00809-01
00 Index and foreword	SEN00810-01
Index	SEN00818-01 ●
Foreword and general information	SEN00819-00
01 Specification	SEN00811-00
Specification and technical data	SEN00820-00
10 Structure, function and maintenance standard	SEN00812-00
Engine and cooling system	SEN01159-00
Power train	SEN01161-00
Steering system	SEN01163-00
Brake system	SEN01166-00
Undercarriage and frame	SEN01168-00
Hydraulic system, Part 1	SEN01170-00
Hydraulic system, Part 2	SEN01172-00
Work equipment	SEN01173-00
Cab and its attachments	SEN01176-00
Electrical system, Part 1	SEN01178-00
Electrical system, Part 2	SEN01179-00
Electrical system, Part 3	SEN01180-00
20 Standard value table	SEN00813-01
Standard service value table	SEN01300-01 ●
30 Testing and adjusting	SEN00814-00
Testing and adjusting, Part 1	SEN01586-00 ○
Testing and adjusting, Part 2	SEN01587-00 ○
Testing and adjusting, Part 3	SEN01588-00 ○
40 Troubleshooting	SEN00815-00
Failure code table and fuse locations	SEN01676-00 ○
General information on troubleshooting	SEN01677-00 ○
Troubleshooting by failure code (Display of code), Part 1	SEN01678-00 ○
Troubleshooting by failure code (Display of code), Part 2	SEN01679-00 ○
Troubleshooting by failure code (Display of code), Part 3	SEN01680-00 ○
Troubleshooting by failure code (Display of code), Part 4	SEN01681-00 ○

Troubleshooting by failure code (Display of code), Part 5	SEN01682-00 ○
Troubleshooting by failure code (Display of code), Part 6	SEN01683-00 ○
Troubleshooting by failure code (Display of code), Part 7	SEN01684-00 ○
Troubleshooting by failure code (Display of code), Part 8	SEN01685-00 ○
Troubleshooting by failure code (Display of code), Part 9	SEN01686-00 ○
Troubleshooting by failure code (Display of code), Part 10	SEN01687-00 ○
Troubleshooting of electrical system (E-mode)	SEN01688-00 ○
Troubleshooting of hydraulic and mechanical system (H-mode)	SEN01689-00 ○
Troubleshooting of engine (S-mode)	SEN01690-00 ○
90 Diagrams and drawings	SEN00817-00
Hydraulic diagrams and drawings	SEN00821-00
Electrical diagrams and drawings	SEN00822-00

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$