



ENGINE REPAIR MANUAL

ENGINE

F4GE9454H

F4GE9454J

F4GE9484D

F4HE9484A

F4HE9484C



READ, UNDERSTAND, AND FOLLOW ALL SAFETY PRECAUTIONS AND INSTRUCTIONS FOUND IN THIS MANUAL BEFORE OPERATING THE MACHINE.

CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer.

This unit first became available 08-2007			
REVISION HISTORY			
Issue	Issue Date	Applicable Machines	Remarks
First Edition	01Aug07	F4GE9454H, F4GE9454J, F4GE9484D, F4HE9484A, F4HE9484C	87630274 NA

ENGINE REPAIR MANUAL

TABLE OF CONTENTS

CHAPTER 1

DIAGNOSTICS

TABLE OF CONTENTS	1-1
TROUBLESHOOTING	1-3

CHAPTER 2

445TA ENGINE OVERHAUL

TABLE OF CONTENTS	2-1
F4GE - ENGINES	2-5
F4HE - ENGINES	2-6
CODING OF SOURCE ENGINES	2-7
ENGINE PROPERTIES	2-8
GENERAL ENGINE FEATURES	2-9
CRANK GEAR COMPONENTS AND CYLINDER ASSEMBLY	2-11
VALVE GEAR - CYLINDER ASSEMBLY	2-14
TORQUE SPECIFICATIONS (F4GE) - ENGINES	2-16
TORQUE SPECIFICATIONS (F4HE) - ENGINES	2-18
SPECIAL TOOLS	2-20
F4GE - ENGINES	2-21
F4HE - ENGINES	2-23
DESCRIPTION OF MAIN ENGINE COMPONENTS	2-24
ACCESSORY EQUIPMENT DRIVE	2-38
COUNTER BALANCER - F4GE ENGINES	2-39
ENGINE LUBRICATION - F4GE ENGINES	2-40
ENGINE LUBRICATION - F4HE ENGINES	2-41
COOLING SYSTEM	2-47
AIR INDUCTION BOOST DIAGRAM	2-49
MECHANICAL INJECTION FEEDING SYSTEM - F4GE ENGINES	2-51
ENGINES WITH BOSCH (VE 4/12 F) ROTARY INJECTION PUMP- F4GE ENGINES	2-54
KKSB COLD START ADVANCE SYSTEM - F4GE ENGINES	2-55
FUEL SYSTEM TEST FOR RESTRICTION OR AIR INFILTRATION - F4GE ENGINES	2-56
HIGH PRESSURE ELECTRONIC INJECTION (COMMON RAIL) - F4HE ENGINES	2-59
EDC7UC31- ELECTRONIC CONTROL UNIT OPERATION	2-60
FUEL SUPPLY SYSTEM - F4HE ENGINES	2-62
COMMON RAIL	2-72
COMMON RAIL PRESSURE RELIEF VALVE	2-73
ELECTRO-INJECTOR	2-74
CHECKING THE FUEL SYSTEM	2-77
SPECIAL DISASSEMBLY - F4GE ENGINES	2-82
SPECIAL DISASSEMBLY - F4HE ENGINES	2-89
CONTINUATION OF ENGINE DISASSEMBLY STEPS FOR ALL ENGINES	2-97
CHECKS AND MEASUREMENTS ON ENGINE CRANKCASE	2-99
CAMSHAFT	2-101
REASSEMBLY	2-102
CRANKSHAFT	2-105
PISTONS	2-109
VALVE GEAR DISTRIBUTION GEARBOX CASE ASSEMBLY	2-118
INJECTION PUMP TIMING FIRST PHASE - F4GE ENGINES	2-120
ASSEMBLING COUNTER BALANCER - F4GE ENGINES	2-121
FLYWHEEL	2-123
MOUNTING THE OIL AND WATER PUMP	2-125
CYLINDER HEAD FOR F4GE ENGINES	2-129
VALVES	2-131
MOUNTING CYLINDER HEAD	2-134
INSTALLING THE INJECTORS	2-137

INSTALLING EXHAUST MANIFOLD, TURBOCHARGER	2-138
INSTALLING INTAKE MANIFOLD	2-138
INJECTION PUMP TIMING	2-141
REPLACING THE INJECTORS	2-144
ROCKER ARM REMOVAL / ASSEMBLY	2-145
CYLINDER HEAD ASSEMBLY - F4HE ENGINES	2-147
VALVES	2-149
VALVE GUIDES	2-150
VALVE SPRINGS	2-153
INSTALLING CYLINDER HEAD	2-153
INSTALLING INJECTORS	2-154
LOCATING TOP DEAD CENTER (TDC)	2-157
ADJUSTING VALVE PLAY	2-158
INSTALLING INTAKE MANIFOLD	2-158
INSTALLING FUEL SYSTEM	2-159

CHAPTER 3

ELECTRICAL, CHARGING AND START-UP

TABLE OF CONTENTS	3-1
LOCATION OF MAIN ELECTRICAL COMPONENTS - F4GE ENGINES	3-3
LOCATION OF MAIN ELECTRICAL COMPONENTS - F4HE ENGINES	3-6
STARTER MOTOR	3-18
ALTERNATOR	3-19

CHAPTER 1

445TA

TIER III

DIAGNOSTICS

Issued 08-2007

Book/Form Number 87630274 NA

Copyright © 2007. CNH America LLC. All Rights Reserved.

Printed in U.S.A. • Bur

Source Code No. unknown

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$