

Shop Manual

BULLDOZER

D375A-6

SERIAL NUMBERS 60631 and up

KOMATSU

SHOP MANUAL

BULLDOZER

D375A-6

Machine model Serial number

D375A-6 60631 and up

00 Index and foreword

Table of contents

00 Index and foreword	
Table of contents	00 - 2
Forward and general information	00 - 13
Safety notice	00 - 13
How to read the shop manual	00 - 18
Explanation of terms for maintenance standard	00 - 20
Handling of electric equipment and hydraulic components.....	00 - 22
Handling of connectors newly used for engines	00 - 31
How to read electric wire code.....	00 - 34
Precautions when carrying out work	00 - 37
Method of disassembling and connecting push-pull type coupler.....	00 - 40
Standard tightening torque table.....	00 - 43
List of Abbreviation	00 - 47
Conversion table	00 - 51
01 Specification	
Specification and technical data	01 - 3
Specification drawing	01 - 3
Specifications	01 - 4
Weight table	01 - 9
Table of fuel, coolant and lubricants	01 - 11
10 Structure and function	
Engine and cooling system	10 - 4
Cooling system	10 - 4
Cooling fan pump.....	10 - 6
Cooling fan motor.....	10 - 26
Power train	10 - 32
Power train	10 - 32
Overall drawing of power train unit	10 - 34
Power train hydraulic equipment arrangement drawing.....	10 - 36
Damper and universal joint	10 - 38
Torque converter and PTO	10 - 40
Torque converter control valve	10 - 46
Main relief valve and torque converter relief valve.....	10 - 48
Lockup clutch ECMV and stator clutch ECMV	10 - 50
Scavenging pump	10 - 55
Transmission control.....	10 - 56
PCCS lever	10 - 58
Transmission.....	10 - 62
Transmission ECMV	10 - 76
Transmission lubrication relief valve	10 - 81
Steering and brake control.....	10 - 82
Transfer unit, bevel gear shaft and steering	10 - 84
Steering control valve	10 - 90
Steering clutch ECMV and Steering brake ECMV	10 - 92
Parking brake valve	10 - 100
Sudden stop prevention valve.....	10 - 101
Final drive	10 - 103
Undercarriage and frame	10 - 108
Track frame	10 - 108
Idler cushion	10 - 110
Track roller bogie	10 - 111
Main frame	10 - 112
Suspension	10 - 114
Hydraulic system	10 - 117
Work equipment hydraulic piping diagram.....	10 - 117
PPC control piping diagram	10 - 121
Work equipment control	10 - 122
Hydraulic tank	10 - 124
Accumulator	10 - 126

PPC lock valve.....	10 - 127
PPC valve	10 - 129
Piston valve.....	10 - 140
Quick drop valve	10 - 141
Pin puller switch.....	10 - 142
Pin puller solenoid valve	10 - 143
Blade control lever (only for the machine with dual tilt specification).....	10 - 145
Work equipment pump.....	10 - 146
Control valve	10 - 158
Self-pressure reducing valve	10 - 182
Work equipment	10 - 189
Cylinder stay	10 - 189
Cab.....	10 - 190
Cab mount	10 - 190
Cab	10 - 191
Electrical system	10 - 194
Engine control	10 - 194
Engine control system.....	10 - 195
CRI engine control system.....	10 - 204
Monitor system.....	10 - 206
Machine monitor	10 - 208
Lamp system.....	10 - 226
Engine preheat (electrical intake air heater) control	10 - 227
Palm command control system.....	10 - 228
Sensor.....	10 - 231
Vehicle health monitoring system (VHMS)	10 - 238
Electric warming and preheating system	10 - 244
Pre-lubrication system	10 - 256

20 Standard value table

Standard service value table	20 - 3
Standard value table for engine	20 - 3
Standard value table for machine	20 - 4

30 Testing and adjusting

Tools for testing, adjusting and troubleshooting.....	30 - 4
Diagnosis equipment list.....	30 - 4
Engine and cooling system	30 - 6
Testing engine speed.....	30 - 6
Testing intake air pressure (boost pressure)	30 - 9
Testing exhaust temperature	30 - 11
Testing exhaust gas color	30 - 14
Adjusting valve clearance	30 - 16
Measuring compression pressure.....	30 - 18
Testing blow-by pressure.....	30 - 21
Testing engine oil pressure	30 - 23
Testing EGR valve drive oil pressure.....	30 - 24
Handling of fuel system devices	30 - 26
Releasing residual pressure from fuel system	30 - 27
Testing fuel pressure	30 - 28
Handling of reduced cylinder mode operation	30 - 29
Handling of no injection cranking operation	30 - 29
Testing leakage from pressure limiter and return rate from injector	30 - 30
Bleeding air from fuel circuit.....	30 - 33
Testing fuel circuit for leakage	30 - 35
Replacing and adjusting alternator and air conditioner compressor belt	30 - 36
Measuring fan speed	30 - 37
Testing fan circuit oil pressure	30 - 38
Bleeding air from fan pump.....	30 - 39
Adjusting fuel control dial and decelerator pedal	30 - 40
Power train	30 - 42
Testing power train oil pressure.....	30 - 42
Adjusting transmission output speed sensor	30 - 58

It's a preview. You can download the full file by
clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$